


## FRONT

**SHARPER  
IMAGE®**


Wireless Earbuds

**User Guide**

SBT543

**In the Box**

Wireless Earbuds

Micro USB  
Charging Cable**Location of Controls**

1. [Power] button:
2. [▶+] button:
3. [ - ◀] button:
4. LED indicator
5. Microphone
6. Micro USB charging port
7. Light mode button:
  - Press once to turn the light on.
  - Press again: Light flashes twice every 2 seconds.


**Pairing the Earbuds**

1. Long press the [Power] button on the side of the earbuds. A voice will be heard and the LED indicator will flash RED and BLUE.
2. Set your Bluetooth-enabled device to search for Bluetooth devices. When your mobile Bluetooth-enabled device finds the speaker, select "SBT543" from the list of found devices.
3. After a successful pairing, a tone will be heard and the LED indicator will intermittently flash BLUE.

**i** If a previously paired device is in range when the earbuds are turned on, they will connect to it automatically.

## On an iOS or Android Device

- Go to **SETTINGS > BLUETOOTH** (Make sure Bluetooth is turned ON)



**i** The screenshots above are typical of many Bluetooth-enabled devices in the market today, and are used to assist in the explanation of the pairing process. Your Bluetooth-enabled device's interface and interaction with the earbuds may differ slightly from the illustrations above.

**Using the Earbuds****Powering ON/OFF**

- Turn the earbuds ON by long pressing the [Power] button. A tone will indicate that the earbuds are powered ON.
  - Turn the earbuds OFF by long pressing the [Power] button. A tone will indicate that the earbuds are powered OFF.
- NOTE:** The earbuds will go into sleep mode after a period of inactivity. While in sleep mode, the LED indicator will flash BLUE intermittently. To wake the device press the [Power] button.

**Answering Phone Calls**

- To answer a phone call quick press the [Power] button.
- To hang up, quick press the [Power] button. Music playback will automatically resume.

**Playing Music**

To enjoy music wirelessly on your earbuds, make sure that they are properly paired to your Bluetooth-enabled device. If you are pairing the device for the first time, please consult the "Pairing the Earbuds" part of this user guide.

**Playing/Pausing Music**

- Quick press the [Power] button to pause the music.
- Quick press the [Power] button again to resume music playback.

**Skipping Songs**

- Quick press the [◀] button to go to the previous song.
- Quick press the [▶] button to go to the next song.

**Adjusting the Volume**

- Long press the [◀] to decrease the volume of music playback.
- Long press the [▶] to increase the volume of music playback.

**Questions and Customer Support**


For further assistance or troubleshooting, please call our customer support line:

Phone: 1-877-768-8481  
Monday-Friday 8AM-10PM (EST)

www.southerntelecom.com  
Click on "Product Support"

**Charging the Earbuds**

Remove the rubber protective seal on the side of the earbuds. Attach the small end of the micro USB cable to the USB port. Connect the large end to your computer or other USB charging device/adaptor. The LED indicator will turn solid RED while charging and turn BLUE when fully charged.



**i** Make sure you charge your earbuds for at least 1-2 hours before using them for the first time.

## BACK

**Legal Information****READ CAREFULLY AND KEEP THIS MANUAL**

**90 Days Limited Warranty**  
In the unlikely event that this product is defective, or does not perform properly, you may within ninety (90) days from your original date of purchase return it to the authorized service center for repair or exchange.

**TO OBTAIN WARRANTY SERVICE:**

- Call the Customer Support number located below, or go to our website portal to receive an SRO number.
- Provide proof of the date of purchase within the package (dated bill of sale).

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

**Limited Warranty**

**Warranty service not provided**  
This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, and unauthorized modification. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

**Limitation of Warranty:**

- THE WARRANTY STATED ABOVE IS THE ONLY WARRANTY APPLICABLE TO THIS PRODUCT. ALL OTHER WARRANTIES, EXPRESS OR IMPLIED (INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE) ARE HEREBY DISCLAIMED. NO VERBAL OR WRITTEN INFORMATION GIVEN BY AIT, INC. ITS AGENTS, OR EMPLOYEES SHALL CREATE A GUARANTY OR IN ANY WAY INCREASE THE SCOPE OF THIS WARRANTY.

• REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER. AIT, INC. SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. THIS DISCLAIMER OF WARRANTIES AND LIMITED WARRANTY ARE GOVERNED BY THE LAWS OF THE STATE OF NEW YORK. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED TO THE APPLICABLE WARRANTY PERIOD SET FORTH ABOVE.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts so the above limitations on exclusions may not apply to you. This warranty gives you specific legal rights, and you also may have other rights that vary from state to state.



Sharper Image® name and logo are registered trademarks. Manufactured and marketed by Southern Telecom under license. © Sharper Image. All Rights Reserved.

**SHARPER IMAGE®**