2. Photograph of the test configuration

3. Sample Calculation

The emission level measured in decibels above one microvolt (dB) was converted into microvolt per meter (/m) as shown in following sample calculation.

For example :

	Measured Value at 447.8 MHz	55.9 dB
+	Antenna Factor	16.3 dB/m
+	Cable Loss	4.0 dB
-	Preamplifier	0.0 dB
-	Distance Correction Factor *	0.0 dB
=	Radiated Emission	76.2 dB /m (= 6456.5 /m)

* Extrapolated from the measured distance to the specified distance by an inverse linear distance extrapolation.