



Test Setup – Modulation Characteristics and Occupied Bandwidth Measurements

- C1) 20' Cable (1.7 dB)
- A1) 30 dB Attenuator (30 dB)
- C2) 20' Cable (1.7 dB)
- A2) 10 dB Attenuator (10 dB)
- A3) 10 dB Attenuator (10 dB)

Test Setup – Conducted Spurious Emissions

- L1) 20' Cable
- L2) 30 dB Attenuator (30 dB Loss)
- L3) 20' Cable
- L4) 10 dB Attenuator (10 dB Loss)
- L5) 10 dB Attenuator (10 dB Loss)
- L6) HPF (LPF)

LPF @890MHz = 14dB
HPF @890MHz >40dB

Test Setup – Radiated Emissions

