

How to use this manual?

Welcome to this manual.

In this Manual, each page is provided with a browsing column separating from browser tool column. You may browse the whole Manual by using the box on the upper left corner or on the bottom.

- Please press the box on the upper left corner to review the inventory list that covers inter-connected chapters.
- Please press the arrow on the left or right for the preceding chapter or the following chapter.
- Please press the upward arrow to return to the beginning of the current page.
- When you have moved your mouse to the location mentioned above, that will show where you have wanted it to be.

No matter which page you are on the Manual now, you can use the browsing column and quickly return to the screen of Contents or Index.

FEDERAL COMMUNICATIONS COMMISSION

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection. This equipment generates, uses and can radiated radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Shielded interface cables must be used in order to comply with emission limits.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.