

MANUAL

FCC ID: J7I10962
MADE IN CHINA

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE:

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER AUTHORITY TO OPERATE THE EQUIPMENT

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.





Includes a
removable and
articulated
Hello Kitty®
figure



INSTRUCTIONS:

To move forward, slide the switch located underneath the scooter to Mode I or Mode II, and then drive using the controller

- **Mode I - Silent Mode:**

Press the right button on the remote control to make the scooter drive straight forward.

Press the left button on the remote control to make the scooter turn backwards and make U turns.

The scooter will move without making any sound in Mode I.

- **Mode II - Sound Mode:**

In this mode the scooter operates with the same functions as in the Silent Mode. The difference is that in this mode the sound "Youhouuu" is also activated when the right button on the remote control is pressed to move forward.

- **TRY-ME Mode:**

This is the stand-by mode. In this mode the remote control functions are disabled so the scooter won't move in this mode, but you can still activate the sound by pressing the Hello Kitty® head on the scooter. We recommend that you position the switch in this mode when your child has finished playing with this toy, in order to save the batteries.



TRY



WARNING:

CHOKING HAZARD—small parts
Not for children under 3 years.

HELLO KITTY Radio Control Scooter

Requ
demo

BATTERY REPLACEMENT:

Requires three "AA" (1.5 Volts) Alkaline batteries. These batteries that are included are for demonstration purposes only.
Also requires one 9 Volt Alkaline battery. This battery is Not Included. **Batteries should only be replaced by adults.**

Directions to insert / replace the scooter batteries:

use a small size Phillips Head screwdriver to unscrew the battery compartment door underneath the scooter. Insert three new "AA" (1.5 Volts) batteries; preferably alkaline batteries. Batteries must be inserted in the correct polarity directions. Then screw the battery compartment door closed. Do not overtighten screws.

Directions to insert / replace the battery in the remote control:

use a small size Phillips Head screwdriver to unscrew the battery compartment cover located on the back of the remote control. Insert a new 9 Volt battery, preferably an alkaline battery. Battery must be inserted in the correct polarity direction. Then screw the battery compartment cover closed. Do not overtighten the screw.

IMPORTANT: if this product is not used for an extended period of time, we recommend that you remove the batteries to extend the battery lifecycle.

CAUTION: Remove all packaging, tags, and ties before giving this toy to a child. Please retain this package for future reference. Products and colors may vary from the pictures shown on this package. Requires three "AA" (1.5 Volts) Alkaline batteries. These batteries that are included are for demonstration purposes only. Also requires one 9 Volt Alkaline battery. This battery is Not Included.

IMPORTANT: Do not use rechargeable batteries.

Exhausted batteries must be removed from this toy, and disposed of carefully, by adults

Do not throw batteries into a fire. Chargeable batteries should be removed from this toy before being charged.

Chargeable batteries must be charged under adult supervision only.

Different kinds of batteries, and new or exhausted batteries, should not be mixed.

Only batteries of the same type (preferably alkaline batteries) or of a similar type should be used.

It is important to insert batteries in the correct polarity direction when inserting batteries.

Supply terminals should not be short-circuited.

When batteries are weak or exhausted, please remove them carefully and drop them at the nearest recycling location for batteries.

CAUTION: Please do not throw this toy away with your normal household trash. When the time comes to dispose of this toy, please bring it to collection points that are specifically designated for electrical and electronic appliances.

Frequency used : 27.145 MHz




**REMEMBER TO SEPARATE ALL
MATERIALS BEFORE RECYCLING**



CARD: Widely recycled.



OTHER: Not currently recyclable.



The Wheeled bin symbol indicates that the product and the batteries must not be disposed of with other household waste as they may contain elements which can have a harmful effect on the environment and human health. Please use designated collection points or recycling facilities when disposing of the item and the batteries.

Pb

HELLO KITTY® is a registered trademark of Sanrio Co., Ltd.
TM & © 2010 Sanrio Corporation. All Rights Reserved.

MANUFACTURED FOR LANSAY FRANCE SA
112 quai de Bezons
95100 Argenteuil - FRANCE

Products and colors may vary from the pictures shown on this package.
All new materials. Surface washable only.
MADE IN CHINA

This product conforms to the safety requirements of ASTM F963 and the European EN71 Safety Standards

DISTRIBUTED BY:
Rainbow Concepts, Inc.
280 North Midland Ave.
Saddle Brook, NJ 07663



conforms to EN71