B4a.1

Base, Channel 1 Power: Hi



B4a.2

Base, Channel 1 Power: Hi



B4b.1

Base, Channel 20 Power: Hi



B4b.2

Bose, Channel 20 Power: Hi



B4c.1

Base, Channel 40 Power: Hi



B4c.2

Bose, Channel 40 Power: Hi



B4d.1

Base, Channel 1



B41.2

Base, Channel 40