


## User Manual

- 1) Turn off the On/Off switch of the vehicle.
- 2) Open the battery door and insert 9.6V Ni-Cd850ttery Pack into the car battery compartment.
- 3) Remove the battery latch of the Transmitter and insert one 9 Volt battery into the hand controller battery compartment.
- 4) The Red LED on the front cover indicates Power On of the Transmitter.
- 5) Turn the On/Off switch of the vehicle to "On" position.
- 6) Push the left control stick upward, the vehicle will go forward. Push the control stick downward and it will go in reverse. Right control stick remain release. The vehicle will stop when both the control buttons are released.
- 7) Push the right control stick rightward, the vehicle will rotate in clockwise direction. Push the right control stick leftward, the vehicle will rotate in anti-clockwise direction. Left control stick remain release. The vehicle will stop when both the control buttons are released.
- 8) Push the left control stick upward, right control stick rightward, the vehicle will go forward and rotate clockwise at the same time.  
Push the left control stick upward, right control stick leftward, the vehicle will go forward and rotate anti-clockwise at the same time.  
Push the left control stick downward, right control stick rightward, the vehicle will go backward and rotate clockwise at the same time.  
Push the left control stick downward, right control stick leftward, the vehicle will go backward and rotate anti-clockwise at the same time.  
The vehicle will stop when both the control buttons are released.



Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encourage to try to correct the interference by one or more of the following measures:

- ☐ Reorient or relocate the receiving antenna.
  - ☐ Increase the separation between the equipment and receiver.
  - ☐ Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- Consult the dealer or an experience radio/TV technician for help.