



國際電器認證中心有限公司 International Electrical Certification Centre Ltd.

提供電器產品測試國際認證及諮詢服務 Technical Services in Electrical Product Testing, International Certification & Information

FCC ID: KVR12158

Agent of 
Accredited Laboratory



Exhibit 5 - User's Manual

Head Office

Unit 602-605, 6/F, 31 Lok Yip Road, On Lok Tsuen, Fanling, NT, Hong Kong Tel (852) 2305 2570 Fax (852) 2756 4480

香港新界粉嶺安樂村樂業路31號6樓602-605室 電話 (852) 2305 2570 傳真 (852) 2756 4480

CORVETTE[®] W/ SOUND[™]




CAR USES
6 "AA" SIZE
(DIAGRAM 1)

Transmitter
REVERSE
PICTURE OF
CONTROLLER
(DIAGRAM 2)

BATTERY LOADING
(FOR MAXIMUM PERFORMANCE,
USE ALKALINE BATTERIES)
REMEMBER TO TAKE OUT ALL BATTERIES
FROM CAR AND TRANSMITTER AFTER
PLAYING.

BATTERY CAUTIONS
1. Non-rechargeable batteries
are not to be recharged.
2. Rechargeable batteries are
to be removed from the key
before being charged.
3. Rechargeable batteries are
only to be charged under adult
supervision. Before adult
uses check the charging facilities
such as car, charger, etc.
4. Alkaline, standard (carbon-
zinc) or rechargeable (nickel-
cadmium) batteries or new
and used batteries are not
to be mixed.
5. Only batteries of the same
or equivalent type as
recommended are to be used.



1. Open battery compartment door at bottom of vehicle and insert 6 "AA" size batteries as indicated, following engraved instructions for correct polarity. (See Diagram 1)
2. Close battery door.

TRANSMITTER



3. On back of transmitter unit open battery compartment and insert one "9-volt" battery. (See Diagram 2)
4. Replace battery cover.

WARNING:

CHOKING HAZARD- Small parts.
Not for children under 3 years.






sensitive electronic mechanism which should
give you many hours of excitement and fun if
you follow the instructions closely. Failure to
care for your car could result in serious
malfunction.



Always hold transmitter at waist level
for best transmission.

PARENT!
Use tweezers to remove foreign matter
from car wheels.

DON'T leave the car switch ON when
not in use. Always turn car OFF to
conserve battery power.



PROPER OPERATION AND STORAGE OF YOUR VEHICLE:

1. Best operation of vehicle is on a low pile carpet.
2. Always operate your vehicle within a range of 15 feet from you.
3. Always operate your vehicle on dry surfaces away from cars and other full-size vehicles.
4. Always store your vehicle in a cool, dry place.
5. Avoid water or damp locations which may damage the vehicle's electronics. If your vehicle ACCIDENTALLY gets wet and stops running, let it dry overnight before trying to run it again.

6. Avoid operating around CB radios, baby monitors, cordless phones, electrical appliances, electric baseboard heaters, high voltage electrical wires and large, steel-reinforced concrete buildings all of which may cause interference.

GUIDE FOR TROUBLESHOOTING:

Check the points below if you are experiencing difficulty. Sometimes an apparent malfunction is the result of a simple cause and effect as shown below.

SYMPOTM	PROBABLE CAUSE	CORRECTION
Vehicle runs slowly or will not run.	• Loose battery connection or switch not ON.	• Check connector and vehicle's ON/OFF switch.
E. After playing with car side the ON/OFF switch of car to the 'OFF' position.	• Weak 9 volt controller battery.	• Replace battery or check.
F. PRESS 'RIGHT' BUTTO	• Weak 9 volt controller battery.	• Replace with fresh alkaline battery.
Sound	• Radio interference likely.	• Change location (see point 6, PROPER OPERATION SECTION).

Trademark of The Goodyear Tire & Rubber Company Used with permission.