

P- 228

10/3

FCC ID: KYIP-228



## ProPad 6



### Introduction

The Performance<sup>TM</sup> ProPad 6 contents include the ProPad 6, Windows<sup>®</sup> 95/98 device driver disk, warranty information, and registration card. If you are missing any of these items, please contact InterAct<sup>®</sup> Multimedia Products' Customer Service at 1-407-333-1392. Please take the time to fill out your warranty and registration card to receive updates and information on new products from InterAct<sup>®</sup>.

### Setting up a Gaming Device in Windows<sup>®</sup> 95/98:

1. Shut down the computer and attach the 15-pin gameport connector to the gameport on the Sound or Game Card.
2. Start Windows<sup>®</sup> 95/98.
3. Insert the ProPad 6 driver into your 3.5" floppy drive.
4. Double-click on the "MY COMPUTER" icon on your desktop.
5. Select the icon for your 3.5" floppy drive (usually drive A:).
6. Choose on SETUP.EXE and follow the directions for installing the ProPad.

### Setting up the ProPad 6 in Windows<sup>®</sup> 3.X and MS-DOS:

Windows<sup>®</sup> 3.X and MS-DOS games that support gaming devices have their own device drivers integrated into their software. Each Windows<sup>®</sup> 3.X and MS-DOS game configures the gamepad differently. You will need to refer to the game manual instructions for calibration.

*Note: If the game has not been setup for the use of a gaming device, the game will default to the keyboard and mouse.*

### Troubleshooting

**SYMPTOM** In Windows<sup>®</sup> 95/98, the control panel tells me that the ProPad 6 is not connected properly.

2/18/2

#### SOLUTION

Make sure that your gameport is functioning properly. Go to CONTROL PANEL, then choose SYSTEM. Click on the DEVICE MANAGER tab, and choose SOUND, VIDEO, AND GAME CONTROLLERS. If there is a yellow or red icon next to GAMEPORT JOYSTICK, then this device is not functioning properly. Contact your system manufacturer for information to fix this.

#### Care for the Unit

The controller is an electronic unit, and should be treated with care when handling. We recommend that you do not store the unit in direct sunlight or at extreme temperatures, or spill any liquids on the unit. Finally, do not open the case of the controller. An InterAct® service technician must do all service and maintenance.

#### Contact Information

##### For the U.S. & Canada

|                 |   |  |
|-----------------|---|--|
| Phone           | : | 1-407-333-1392   |
| Email           | : | pcsupport@gameshark.com  |
| World Wide Web  | : | <a href="http://www.interact-acc.com/">http://www.interact-acc.com/</a>  |
| Mailing Address | : | InterAct® Accessories, Inc.<br>ATTN: CUSTOMER SERVICE<br>A Recoton Company<br>2950 Lake Emma Road<br>Lake Mary, FL 32746 |

##### For United Kingdom (England, Scotland, Wales, and Northern Ireland) and Ireland:

|                 |   |   |
|-----------------|---|---|
| Phone           | : | 44 1204 862 026   |
| Fax             | : | 44 1204 862 033   |
| Email           | : | <a href="mailto:info@Rossep.com">info@Rossep.com</a>      |
| World Wide Web  | : | <a href="http://www.rossep.com">www.rossep.com</a>        |
| Mailing Address | : | Ross<br>Emlyn St. Farnworth<br>Bolton, BL4 7EB<br>England |
| Hours           | : | Monday through Friday 900 hrs. to 1700 hrs.               |

All trademarks are the property of their respective owners.

Printed in Hong Kong

P-228

3 of 3

## **FCC REGULATIONS**

This equipment generates and uses radio frequency energy and if not installed and used properly, that is, in strict accordance with the manufacturer's instructions, may cause interference to radio and television reception. It has been type tested and found to comply with the limits for a Class B computing device in accordance with the specifications in Subpart B of Part 15 of FCC rules\*, which are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference, if any, will not occur in a particular installation. If this equipment does cause interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient the receiving antenna.*
- Relocate the computer with respect to the receiver.*
- Move the computer away from the receiver.*
- Plug the computer into a different outlet so that computer and receiver are on different branch circuits.*

If necessary, the user should consult the dealer or an experienced radio/television technician for additional suggestions. The user may find the following booklet prepared by the Federal Communications Commission helpful:

*\*How to Identify and Resolve Radio-TV Interference Problems.*

This booklet is available from the U.S. Government Printing Office, Washington, DC 20402; Stock No. 004-000-00345-4.

The manufacturer is not responsible for any radio or TV interference caused by unauthorized modification to this equipment. It is the responsibility of the user to correct such interference.