

JP-46338 Remote Car Instruction Manual

FEATURES:

CAR LENGTH: 180 MM

FUNCTIONS: Forward, Turn left, Turn right, Stop
Reverse left, Reverse right, Headlights.

BATTERY INSTALLATION

- Open the battery compartment cover at the bottom of the car, install four "AA" nickel Cadmium or Alkaline batteries, whereas, for the transmitter, use one 9V battery.
- Make sure the polarity (+ and -) is correct.
- Use Nickel Cadmium or Alkaline batteries instead of the ordinary type can achieve the best performance for your car.

OPERATION

- Extend the antenna of the controller to full length.
- For maximum range of control always keep the antennae straight up and hold the transmitter at upright position.
- Set the power switch of car to "ON" position.
- Use two hands to operate the control sticks. On the left hand side, the level control the car to go forward and backward, whereas, the right hand side lever controls it's forward and backward turning actions.
- Attempt to operate the forward/backward action, and turning action at the same time.
- Plug the earphone into the earphone jack. You can receive the voice nearby the car,
This is called "SPY".
- If the car does not go straight, adjust the 'ALIGNMENT' at the bottom of the car.
- When not in use, switch OFF the car. If you do not intend to use the car for a long time, remove the batteries, weak or dead batteries can leak damaging chemicals.
- For best performance, use alkaline batteries.

HINTS

- Since the unit operates on 27 MHz, you may experience interference from CB radio, which is in the same band of frequencies. Under such conditions, better change location or wait until interference ceases. Also two or more R/C cars (or other devices) cannot operate in the same area, they may interfere each other.
- Range of operating distance will depend on surroundings, buildings, and large metal objects. You will obtain better performance in open area.
- Never operate your car in the street, in water, sand, or on thick carpet, do not allow it to go through rain, rust can be formed inside hair or dust. Remove such materials from the wheel bearings carefully.
- Do not allow the car to fall off a high sledge, a fall might damage it.
- Never disassemble your car or the transmitter.
- Do not store the car either near a source of heat or in direct sun for an extended period.

NOTE: THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

"Modifications not authorized by the manufacturer may void users authority to operate this device"

NOTE:

This equipment has been tested and found to comply with limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct this interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

