

QUICKART 2000

OWNER'S MANUAL

OPERATING INSTRUCTIONS

TRAINING GUIDE

TABLE OF CONTENTS

<u>TOPIC</u>	<u>SECTION</u>
Owner's Manual and Operating Instructions	1
Troubleshooting Flowchart	2
Training Manual	3
Certified Operator's Test.....	4

Note on radio equipment used:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Changes not expressly approved by Dane Technologies could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The abbreviation IC, before the Canadian Registration Number signifies that registration was performed based on a Declaration of Conformity indicating that Industry Canada technical specifications were met. It does not imply that Industry Canada approved the equipment.

The CE mark, if present, declares that this equipment meets relevant EU Directives and Standards.

PROGRAMMING THE REMOTE CONTROL

Each hand-held remote control transmitter operates on a unique pre-programmed code. For the QuicKART to operate in the Remote Mode, the receiver, which is in the beacon tower, must be programmed to match the hand held remote control. Every time the batteries in the remote control are replaced, the remote control needs to be reprogrammed to match the receiver code in the beacon tower. If the QuicKART stops responding to the remote control, check the status of the remote battery by depressing one of the remote buttons. If the red LED light does not illuminate, change the battery and reprogram the remote control as follows:

- 1) Turn on the QuicKART.
- 2) Switch to "**RADIO**" on the control panel.
- 3) Hold remote about arms length from the beacon post.
- 4) Simultaneously push these three buttons:
 - Rubber button located on the underside of the square box on the beacon post (see pages 15 and 16);
 - Brake button on the hand-held remote (page 22);
 - Horn button on the hand-held remote (page 22).
- 5) The horn should sound indicating the reprogram is complete and the QuicKART is ready for operation.
- 6) If the horn did not sound, retry the above steps making sure that the switch on the control panel is on "**RADIO**". If the horn still did not sound, you can also determine if the reprogram was successful by pressing the slow button on the remote to see if the QuicKART now responds to the remote signal.