



good call™

USER MANUAL

***Bluetooth®* Handset**

(iG1/iG1HD)


WELCOME

Congratulations on the purchase of your new
good call™ Bluetooth® Handset

the world's next generation of *Bluetooth* wireless technology. Your good call™ Handset has been designed for optimal use in the home or office. Good Call is all about celebrating the art of conversation in a safe, comfortable, convenient and sexy fashion.

Made for


iPhone 4S, iPhone 4, iPhone 3GS, iPhone 3G



CONTENTS

HANDSET LANDSCAPE.....	6
GET JUICED.....	7
PAIR IT UP.....	8
SYNC iPHONE.....	10
FEATURES.....	11
SPECS.....	12
LIGHTS n' ACTION.....	13
TROUBLESHOOTING.....	14
WHAT'S IN THE BOX?.....	15
SAFETY INFORMATION.....	16
SUPPORT.....	19


HANDSET LANDSCAPE



GET JUICED


Power Up

- a) Plug the USB cable into the AC Power Adapter.
- or
- b) Plug the USB cable into your computer.



Charging

Make sure the dock is powered up then dock your Handset and *iPhone*.



*Your good call™ Handset is partially charged and is ready for use right out of the box.

PAIR IT UP

Prepare your good call™ Handset^(see page 9)

- Slide the On/Off Switch to **ON**.
- Press and hold the Call() button for 3 seconds until you hear the startup sound.

Prepare your iPhone®


- Go to Settings > General > Turn ON *Bluetooth*
- When “Good Call” appears, select it.

NOTE: The (top) LED will turn white on your good call™ Handset indicating a successful *Bluetooth* connection.

Pairing unsuccessful?


- Restart your *iPhone*.
- Then **Slide** the On/Off Switch to **OFF** on your good call™ Handset. Repeat the pairing process above.

To reconnect*

- Press the End() button OR
- Slide** the On/Off switch to OFF then ON.

b)  **Hold**

a)  **slide**



NOTE: This is a one-time pairing process.

SYNC iPhone

Syncing with iTunes:

1. Be sure that the good call™ Dock is connected via USB to the computer on which your iTunes is located.
2. Dock your *iPhone*.



FEATURES

Call n' End

Press the Call(**☎**) button to answer and make calls.
Press the End(**⏏**) button to terminate calls.

Make a Call

Dial the number on your *iPhone* or use the feature below.

Siri / Voice Dialing

Hold the Call(**☎**) button for 1 second > you will hear a beep > say your command.

Redial

Press the Call(**☎**) button twice.

Auto Answer / Hang up

Lift the handset from the base, to automatically answer incoming calls. Put the handset back in the base, to automatically end all calls.

Volume

Press Volume Up(+) or Volume Down(-) during a call to adjust the voice and ringer volume.

Reconnect*

Press the End(**⏏**) button or **Slide** the On/Off switch to OFF then ON.

NOTE: *In order to preserve battery life your Handset will automatically go into standby mode. To wake up the Handset and reconnect, follow instructions above.

Mute n' Unmute

Hold the Volume Down(-) button for 2 seconds and you will hear a beep.

Call Waiting

Press the Call(**☎**) button to toggle between incoming and existing calls.

Ringer Imitation

Your good call™ Handset will automatically have the same ringtone as your *iPhone*(example: Marimba).

NOTE: This feature only works with iPhone 4S and iPhone 4.

SPECS

Size and Weight:

Handset

Height: 7.3 inches

Width: 1.9 inches

Depth: 1.3 inch

Weight: 3.5 ounces

Dock

Height: 1.9 inches

Width: 5.7 inches

Depth: 3.2 inch

Weight: 11.6 ounces

LIGHTS n' ACTION

Bluetooth Status

Connected - White LED is on.

Standby Mode - White LED will flash.

Conversation Status


Ringing - White/Red LED will flash.

Talking - Blue LED is on.

Battery Status

Low Battery - Red LED is on.

Charging - Red LED is on.



TROUBLESHOOTING

Handset doesn't automatically reconnect!

- a) Press the End(⏏) button OR
- b) **Slide** the On/Off switch to OFF then ON.

NOTE: In order to preserve battery life your Handset will automatically go into standby mode. To wake up the Handset and reconnect, follow instructions above.

I can't pair my *iPhone*!

- a) See page 8 and follow the pairing instructions. Make sure your *iPhone* is within 3 feet of your good call™ Handset when pairing.
- b) Turn OFF your good call™ Handset. Restart your *iPhone*. Then repeat the pairing process.

Others can't hear me!

- a) Speak closer to the microphone.
- b) You may be on mute. To unmute, hold the Volume Down(-) button for 2 seconds.

Experiencing Signal Loss?


- a) Move your *iPhone* closer to the good call™ Handset.
- b) Your *iPhone* may have poor reception. Try moving it for better reception.

good call™ Handset isn't working?

- a) Make sure the good call™ Handset is charged.
- b) Make sure the good call™ Handset is paired.
- c) Turn up the volume on your good call™ Handset.

WHAT'S IN THE BOX

- 1) good call™ *Bluetooth*® Handset
- 2) good call™ Dock
- 3) USB Cable (plug into AC Power Adapter or computer)
- 4) AC Power Adapter
- 5) User Manual



SAFETY INFORMATION

Warning

Please read these safety warnings carefully to ensure your personal safety and prevent property damage.

LIMITED WARRANTY & SAFETY INFORMATION

GoFusion LLC (GoFusion) warrants this product from defects in material and workmanship for a period of one (1) year from the date of original purchase. A copy of the receipt showing proof of purchase must be enclosed with any return in order for the return to be valid. Provided the product has not been willfully or neglectfully used, GoFusion will repair or replace the Product at no charge or, at GoFusion's option, refund the purchase price shown on your receipt during the warranty period. To obtain warranty service within the United States, you must take the Product, or deliver the Product freight prepaid, in its original packaging to:

**GoFusion Support
1204 Avenue U
Brooklyn, NY 11229**

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER. GoFusion SHALL NOT BE LIABLE FOR ANY INCIDENTAL, INDIRECT OR CONSEQUENTIAL DAMAGES INCLUDING BUT NOT LIMITED TO, LOSS OF PROFITS, LOSS OF REVENUE, LOSS OR CORRUPTION OF DATA, LOSS OF USE OF THE PRODUCT OR ANY ASSOCIATED EQUIPMENT, DOWNTIME AND USER'S TIME OR FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY OR CONDITION, BREACH OF CONTRACT, NEGLIGENCE, STRICT LIABILITY OR ANY OTHER LEGAL THEORY RELATED TO THIS PRODUCT. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY/CONDITION OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY. ANY WARRANTY FOR INTELLECTUAL PROPERTY INFRINGEMENT IS HEREBY DISCLAIMED.

This Limited Warranty gives you specific legal rights, and you may have other rights which vary from state to state, territory or province. GoFusion recommends you email us at customerservice@gofusion.com before returning this product to ascertain if in fact the product is under warranty. The forgoing warranty is limited and is not applicable to: (i) normal wear and tear; (ii) defects or damage caused by misuse, accident (including without limitation collision, fire and the spillage of food or liquid), neglect, abuse, alteration, unusual stress, modification, improper or unauthorized repair, installation, wiring, testing or improper storage. To reduce the risk of fire or electrical shock do not expose the product to rain or moisture or fire. Do not insert any foreign objects in the handset. THE LIMITED WARRANTY SET FORTH ABOVE IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES AND GoFusion HEREBY DISCLAIMS ALL OTHER WARRANTIES OF ANY KIND, WHETHER EXPRESS, IMPLIED, STATUTORY OR OTHERWISE, INCLUDING WITHOUT LIMITATION ANY WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR USE OR PURPOSE, NON-INFRINGEMENT, QUALITY AND TITLE. GoFusion DOES NOT WARRANT THAT THE PRODUCT IS ERROR FREE OR THAT IT WILL FUNCTION WITHOUT INTERRUPTION.

AVOID HEARING DAMAGE!

Permanent hearing loss may occur if the good call™ Handset is used at a high volume and kept at your ear for prolonged periods of time.

BUILT-IN BATTERY CARE:

Your product is powered by a rechargeable battery. The full performance of a new battery is achieved only after two or three complete charge and discharge cycles. The battery can be charged and discharged hundreds of times, but will eventually wear out. Unplug the charger from the electrical plug and the product when not in use. Do not leave a fully charged battery connected to a charger, since overcharging may shorten its lifetime. If left unused, a fully charged battery will lose its charge over time. Leaving the product in hot or cold places will reduce the capacity and lifetime of the battery. Temperatures between 59°F and 77°F are best.

BATTERY WARNING!

Caution – The battery used in this product may present a risk of fire or chemical burn if mistreated. Do not attempt to open the product or replace the battery. It is built-in and not replaceable. Use of other batteries may present a risk of fire or explosion and the warranty will be terminated. Only recharge your battery with the provided charger designated for this product. Dispose of batteries according to local regulations. Please recycle when possible. Do not dispose as household waste or in a fire as they may explode. Batteries may explode if damaged.

FCC STATEMENT:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

SUPPORT

call

866 211 6426

visit

www.goodcallbro.com/support

*We appreciate your feedback, so please fill out
our customer feedback form online at:*

www.goodcallbro.com/customerfeedback

Find us on Facebook and Twitter:



www.goodcallbro.com/facebook



twitter.com/goodcallbro



***Bluetooth®* Handset**

Made for

iPhone 4S, iPhone 4, iPhone 3GS, iPhone3G

TM 2011 GoFusion LLC. All rights reserved.

The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by GoFusion, LLC, is under license. Patent pending.

“Made for iPhone” means that an electronic accessory has been designed to connect specifically to iPhone and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPhone may affect wireless performance. iPhone is a trademark of Apple Inc., registered in the U.S. and other countries.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.