

## EXHIBIT C – Installation Instructions

FCC ID O77-WTX-SERIES



## INSTALLATION INSTRUCTIONS

### DIGITAL TRANSMITTER MODEL WTX 3500

Congratulations! You have just purchased a WTX 3500 Digital Transmitter, which we believe to be the finest product of its kind on the market. With a little care this transmitter should provide you with many years of excellent service. Please take a moment to read the following instructions.

#### TRANSMITTER INSTALLATION

The transmitter is completely self-contained, including battery, and is operated while mounted in the car. It is supplied with a clip for attaching to the sun visor, if desired.

#### TRANSMITTER BATTERY REPLACEMENT

Replace the battery – 9 volt NEDA 1604(Eveready 216 or equivalent).

The battery in the transmitter can be checked or changed by removing the battery access door on the back of the transmitter. Sliding the door down towards the bottom of the transmitter can open the door, this will expose the battery compartment.

#### TO REPLACE OR ADD A SET

A replacement or new transmitter or receiver may be purchased by specifying the Model Number designated on the identification label. The RF frequency is set at the factory and must not be adjusted in the field.

#### OPERATIONAL CHECK

To check operation, move back a reasonable distance (about 50 feet) and press the transmitter button. Operation should be reliable at this distance but environment and location of both the transmitter and receiver will affect the range. If the transmitter is stowed well out of sight, it may be necessary to remove it from its mounting and hold near the windshield. Try different locations and positions. If operation is still unsatisfactory, the problem may be isolated by:

1. Checking the door operator. If the door will not open when the wall button is pressed, the problem is likely to be the operator. If the door will open by pressing the wall button, but not when the transmitter button or buttons are pressed, the problem is probably in the transmitter.
2. Replacing the transmitter battery. If after performing the above operational checks, the controls still do not function, they should be returned to your dealer for repair or replacement.

**CAUTION:** Any changes or modifications in intentional or unintentional radiators which are not expressly approved by AMERICAN DIGITAL TECHNOLOGIES could void the user's authority to operate this equipment. This applies to intentional and unintentional radiators certified per part 15 of the FCC rules and regulations.