




A. CONTROLLER

1. UNSCREW THE BATTERY COMPARTMENT COVER.
2. PLACE ONE 9V. ALKALINE BATTERY INSIDE THE COMPARTMENT AS THE ENGRAVED POSITION.
3. PUSH OR PULL THE STICKS FOR FORWARD AND REVERSE. TURN LEFT, TURN RIGHT, OR TURN AROUND.

**B. CAR**

1. TURN OUT THE LOCK AND TAKE OUT THE BATTERY BOX FROM THE CHASSIS OF THE CAR.
2. PLACE FOUR "AA" OR "UM-3" SIZE ALKALINE BATTERY INTO THE BATTERY BOX AS THE ENGRAVED POSITION.
3. PUT THE BATTERY BOX INTO THE CHASSIS AND PUSH IT FORWARD. TURN THE LOCK ON TO PREVENTED THE BATTERY BOX COME OUT AND POOR CONTACT.
4. DO NOT MIX NEW AND OLD BATTERIES TOGETHER.
5. DO NOT MIX ALKALINE, LITHIUM OR OTHER KIND SAME SIZE BATTERIES TOGETHER.
6. DO NOT USE RECHARGEABLE BATTERIES.
7. ONLY BATTERIES OF THE SAME OR EQUIVALENT TYPE AS RECOMMENDED ARE TO BE USED.
8. THE SUPPLY TERMINALS ARE NOT TO BE SHORT-CIRCUITED.
9. ALWAYS REMOVE OUT EXHAUSTED OR DEAD BATTERIES FROM THE PRODUCT.
10. WHEN STORING FOR A LONG PERIODS OF TIME, REMOVE OUT THE BATTERIES.

SGS HK LTD
31 OCT 2001
REC'D / PWY LWS

**NOTE:**

The users manual or instruction manual for an intentional or unintentional radiator shall caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.