

Table of Contents

Section	Contents
1	Introduction
	Preface ----- 1
	Peripheral Component Interconnect (PCI) Bus Overview ----- 2
	Product Description ----- 5
	Remote Wake-Up Support ----- 7
	Auto-Negotiation Support ----- 7
	Feature ----- 8
	Package Contents ----- 10
2	Hardware Installation
	Step 1. Insert Card into Computer ----- 12
	Step 2. Connecting to the Network ----- 15
	Step 3. Connecting the Remote Wake-Up cable ----- 17
	Step 4. Network Cable Connection Examples ----- 19
	. Connecting to 100BASE-TX Fast Ethernet Network
	. Connecting to 10BASE-T Ethernet Network
	Correct Network Cable(STP/UTP) Requirements ----- 23
Section	Contents
	Automatic Selection of the Media Type ----- 24
	10/100 Auto-Negotiation (NWay) ----- 24
	Remote Boot ROM Installation ----- 25
3	LED Indicators
	LED Indicators ----- 27

4	The Setup Program	
	Performing the RSET8139.EXE Program	-----
1.	View Current Configuration	----- 32
2.	Set Up New Configuration	----- 34
3.	Run Diagnostics	----- 35
<hr/>		
5	Software Installation	
	Installing Network Drivers	----- 43
	Software Installation Examples	----- 43
<hr/>		
A	Adapter Specifications	
B	Appendix	
	UTP Cable	
	RJ-45 Connector Pin Assignments	

Icons

Information  notes for important features or instructions.

FEDERAL COMMUNICATIONS COMMISSION

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection. This equipment generates, uses and can radiated radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Shielded interface cables (except power cord) must be used in order to comply with emission limits.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.