


REMOTE KEYCHAIN TRANSMITTER (RA-02R) USER MANUAL

The Keychain Transmitter conveniently fits on any keychain. It allows you to arm and disarm the system from a distance of approximately 50 feet from the ABS-1000. The distance will depend on what is between the keychain transmitter and ABS-1000.

Note: Make sure you press down on the transmitter for one full second or the system may not respond.



TO ARM SYSTEM USING THE KEYCHAIN TRANSMITTER

Press button Key 1, and the ABS-1000 will beep once. The system will be armed.

TO DISARM THE SYSTEM, OR DEACTIVATE THE SIREN USING THE KEYCHAIN TRANSMITTER

A) When the system is armed:

Press button Key 2

The red light on the transmitter flashes and the ABS-1000 beeps twice.
The system is now disarmed.

B) When the siren is sounding:

Press button Key 2

The red light on the transmitter flashes and the siren deactivated.


KEYCHAIN TRANSMITTER BATTERY

The Keychain Transmitter operates on a 12 volt battery which is installed at the factory.

There are two screws on the back of the transmitter that holds the case together.

To replace the Keychain Transmitter battery:

1. Undo the two screws on the back of the transmitter.
The back will then come off.
2. Using a small screwdriver or pen knife, pry out the old battery from one end
3. Place the new battery in position.
A diagram beside the battery well indicates which end is positive and which is negative.
4. Close the battery cover and reinsert the two screws.



Warning : Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- Consult the dealer or an experienced radio/TV technician for help.

END