

smaxtec



smaxtec

CLASSIC BOLUS SX.2 QUICKSTARTGUIDE

CONTENT



smaXtec

1x




1.






Please ensure that your smaXtec Base Station is activated and ready for use before starting the bolus initialisation process.

2.



Switch on bolus with magnet



The magnet used for bolus initialisation is delivered with the smaXtec Base Station.



2



☀ No blinking pattern



Ensure that you are within the read-out range of the Base Station and repeat the process once or twice.



smaXtec support

3. Assign bolus to an animal





The activation process is only completed when the bolus is assigned to an animal. This step is mandatory: Data will only be generated and displayed for assigned boluses.

4.



Administer the boluses the same day with the smaXtec bolus applicator.





messenger.smaXtec.com

SMAXTEC MESSENGER



Find more information on how to use the smaXtec Messenger via

> User Account > About

© 2021 smaXtec animal care GmbH. All rights reserved.

smaXtec® is a trademark of smaXtec animal care GmbH.
This trademark may not be used without permission of
smaXtec animal care GmbH.

This user manual may not be copied. Changes regarding
this document will not be announced. Before using the
smaXtec products, please check if there is a new version
of this document available on the website:

<http://www.smaxtec.com>

Changes or modifications not expressly approved by the
party responsible for compliance could void the user's
authority to operate the equipment.

This device complies with Part 15 of the FCC Rules.
Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including
interference that may cause undesired operation.

This device contains licence-exempt transmitter(s)/
receiver(s) that comply with Innovation, Science and
Economic Development Canada's licence-exempt RSS(s).

Operation is subject to the following two conditions:

- (1) This device may not cause interference
- (2) This device must accept any interference, including
interference that may cause undesired operation
of the device.

Cet appareil contient des émetteurs / récepteurs exemptés
de licence conformes aux RSS (RSS) d'Innovation,
Sciences et Développement économique Canada. Le
fonctionnement est soumis aux deux conditions suivantes:

- (1) Cet appareil ne doit pas causer d'interférence
- (2) Cet appareil doit accepter toutes les interférences,
y compris celles susceptibles de provoquer un
fonctionnement indésirable de l'appareil.

SMAXTEC SUPPORT



**You have questions
or need assistance?**

We are happy to help!

Support International

T +43 316 46 15 88 - 80

Belgiergasse 3 · 8020 Graz · Austria
E support@smaXtec.com