

Logos Av Com - Via Risorgimento, 22 - 48018 Faenza - Italy

tel +39 0546 622 080 - fax +39 0546 622 090 - www.logosav.com

Televoter Controller USER MANUAL

(FCC ID OM4 TLVUCT4K)



Operating instructions

To operate the system, keep to the following instructions:

Connect the PC Com 1serial exit to the serial outlet of the controller located on the side where the supply cable comes out.

Fasten the connectors by means of the special screws.

Connect the outlet of the control unit to the power mains (110 Volt 60 Hz).

The special red pilot light shall signal that the unit is powered.

Connect the PC to the power mains and switch it on.

Keep to the instructions provided by the PC manufacturer and start the software.

Software

Many kind of software are available to operate the Controller; keep to the instruction of the software supplier.

Controller installation

The controller shall be installed in a position visible from the whole hall; it should be placed in the middle of the hall, in an upper position. If necessary, use an extensible staff with tripods.

CAUTION

Changes or modifications not expressly approved by the manufacturer for compliance could void the user's authority to operate the system.

NOTE - This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.