


## Buttons and interfaces



1. Turn on/off: Press and hold for 3 seconds
2. Press for skip backward to the previous track  
Hold for volume up
3. Press for skip forward to the next track  
Hold for volume down
4. Play/button
5. Bluetooth button
6. Press to get in TWS mode
7. Indicator
8. DC 5V input
9. Aux IN

## Product parameters

Operating range	10m
Channel	Single
Impedance	4Ω
Output power	5W
SNR	≥80dB
Speaker unit	Diameter 40mm
Audio	MP3/WMA/WAV
Battery capacity	1500mAh
Play time	6H
Material	Plastic
Product size	85*85*103mm
N.W	370g



### WARNING

Always confirm that the temperature is 5°-40°c before you charge the battery. Please send it to professionals if there is something wrong. Do not overhaul by yourself.

## USER MANUAL



**AIWA Exos Go**

## Connecting

Press and hold the on/off button. The speaker says “Powering on”. The blue LED light will flash rapidly. Search on your Bluetooth devices and find “AIWA Exos Go” to connect. You will hear a prompt “Connected”, which means the speakers are successfully connected with your Bluetooth devices.




## Indicator

1. Blue light blinking fast: Ready to connect  
Blue light stays on: Connected successfully  
Blue light slow: Playing
2. Green light blinking: Ready for pairing  
Green light stays on: Pairing successfully
3. Orange light stays on: Charging  
Orange light stays off: Charging completed

## TWS function

TWS feature allows you to pair two speakers together to create the ultimate surround sound experience.

Connection method: open two AIWA Exos Go devices first; short press "  " button, you will hear a short tone, then the speakers should automatically link together, you will hear a ring to confirm the link was successful. You can connect your mobile phone to the AIWA Exos Go after paired successful.

(Note: Do not use your mobile phone to connect the speaker until the two speakers are paired.)


## Bluetooth button

If the connection is slow, press the Bluetooth button twice to refresh or power on the speaker again. Then connecting again will speed up the connection.

## ACCESSORIES



USB-C charging cable



AUX cable

**FCC Warning**

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**FCC Radiation Exposure Statement:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.