



1. THE TWO WALKIE TALKIES AND BASE STATION ARE ON THE SAME FREQUENCY. WHEN ALL UNITS ARE ON, THREE PEOPLE CAN COMMUNICATE WITH EACH OTHER AT THE SAME TIME.
2. OPEN BATTERY COMPARTMENTS AND SNAP IN ONE 9- VOLT BATTERY. CLOSE BATTERY COMPARTMENT.
3. TURN THE ON/OFF/VOLUME CONTROL TO DESIRED SOUND LEVEL.
4. FOR HAND HELD WALKIE TALKIE, PRESS THE PUSH TO TALK BUTTON FOR TRANSMITTING WHILE SPEAKING INTO THE SPEAKER/MICROPHONE GRILLE.
5. RELEASE THE PUSH TO TALK BUTTON FOR RECEIVING.
6. FOR MORSE-CODE SIGNALS, PRESS THE MORES CODE BUTTON MOMENTARILY AND RELEASE FOR DESIRED SIGNALS. PUSH THE PUSH-TO-TALK BUTTON AT THE SAME TIME FOR TRANSMITTING MORSE CODE.
7. REQUIRE 2 9 VOLT BATTERIES (NOT INCLUDED).
8. THE UNITS MAY HAVE FEEDBACK (SQUEALING NOISE) WHEN PLAYED TOO CLOSE TOGETHER. MOVE FARTHER APART WHEN IT HAPPENS.

1. ON-OFF BUTTON
2. FLEXIBLE SAFETY ANTENNA
3. MORSE CODE KEY
4. PUSH-TO-TALK SWITCH
5. SPEAKER MICROPHONE
6. BELT CLIP
7. BATTERY DOOR

**CAUTION:**

1. YOUR TRANSCOMMUNICATOR HAS BEEN FULLY ADJUSTED PRIOR TO SHIPMENT FROM THE FACTORY AND BE SURE NOT TO TOUCH THE INTERNAL COMPONENTS OTHER THAN REPLACING THE BATTERY.
2. WHEN THE SOUND BECOMES WEAK, TO CHANGE THE BATTERY.
3. AFTER USE, ALWAYS RETURN THE ON-OFF SWITCH TO THE OFF POSITION.
4. BASE STATION EQUIPPED WITH A BREAKAWAY BUCKLE AS A SAFETY PRECAUTION TO AVOID POSSIBILITY OF ENTANGLEMENT OR STRANGULATION. DO NOT ADD ANY STRINGS OR STRAPS TO THE BASE STATION OR IN ANY WAY BY PASS THE BREAKAWAY BUCKLE.

**WARNING:** THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THE EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

## **FCC Warning Statement:**

This equipment has been tested and found to comply with the limits for a Class B Digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not instructions, may cause harmful interference no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, that the user is encouraged trying to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.