


# WiFi Adapter User Manual

1. Open the driver folder and double-click the installation file, Click "Install" to finish the installation.

Drive download: Enter "<http://szcomfast.com/>" and click "Download Help" and then search for "CF-811AC" and "click to download".



2. After confirming that the driver is installed correctly, you can double-click the wifi icon in the bottom right corner, and click the icon with the left mouse button. The computer will display the connectable WiFi SSIDs.

← Wi-Fi



SHZL-COMFAST-5G



COMFAST\_46ED\_5G



--wpa1--aes--1234567890



--wpa2--aes--1234567890-5g



2.4G\_COMFAST\_38449D



222aJkL222

More Wi-Fi settings

3. Click the WiFi SSID you want to connect and input the password.

← Wi-Fi



SHZL-COMFAST-2G-plus



SHZL-COMFAST-5G

Secured

Enter the network security key

••••••••••



You can also connect by pushing the button  
on the router.

Next

Cancel



TOGO



TD-LINK TD-FL3000

More Wi-Fi settings

4. After connected, open the "Open Network & Internet setting", click the "Wi-Fi" option, you can find the connected WiFi SSID, view the current IP, MAC address, gateway, driver version, etc.

SHZL-COMFAST-5G properties

Connect automatically when in range

**Public (Recommended)**  
Your device is not discoverable on the network. Use this in most cases—when connected to a network at home, work, or in a public place.

**Private**  
Your device is discoverable on the network. Select this if you need file sharing or use apps that communicate over this network. You should know and trust the people and devices on the network.

Configure Firewall and security settings

Metered connection  
Some apps might work differently to reduce data usage when you're connected to this network **Off**

Set a data limit to help control data usage on this network

IP assignment:	Automatic (DHCP)	<a href="#">Edit</a>
DNS server assignment:	Automatic (DHCP)	<a href="#">Edit</a>
SSID:	SHZL-COMFAST-5G	<a href="#">Copy</a>
Protocol:	Wi-Fi 5 (802.11ac)	
Security type:	WPA2-Personal	
Manufacturer:	Realtek Semiconductor Corp.	

Note: If the IP address is not obtained or the data packet is not received, the password may be entered incorrectly. Please re-enter the correct password to obtain the IP again. For networks with fixed IP addresses, you need to manually set the IP address.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.

Specific Absorption Rate (SAR) information:

This device meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. FCC RF Exposure Information and Statement the SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: This device has also been tested against this SAR limit.

This device was tested for typical body-worn operations with the back of the This device kept 0mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain an 0mm separation distance between the user's body and the back of This device. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.