

*** USER'S MANUAL ***

FCC ID : OZIRC-01

Federal Communications Commission (FCC) Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

Warning : A shielded-type power cord is required in order to meet FCC emission limits and also to prevent interference to the nearby radio and television reception. It is essential that only the supplied power cord be used.

Use only shielded cables to connect I/O devices to this equipment.

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

INSTRUCTIONS FOR USE

1. INSTRUCTION

Congratulations on your purchase of the SanShih Power Control System (RR-02).

This system contains one remote control (RC-01) and 3 Power switches (RR-04) With Power Remote Control system you can operate electrical appliances in and around your house via the remote control without getting out of your chair !

2. QUICK REFERENCE

1. Install the enclosed battery in the remote control (fig. 1).

2. Connect the Power switches to a main power outlet (fig. 2).

3. Select the appliances, e.g. lamp which you want to control and plug them into the Power switches (fig. 2). Check the power consumption of the selected appliance before plugging them into the Power switches. The Power switches can control appliances with a maximum power rating of 1000 Watts! If the selected appliances have their own ON/OFF switch, make sure they are switched on.

4. Use the remote control to operate the appliances (fig. 3).

The Power switches are operated with button 1,2 and 3 as its default setting.

If the right button is pressed, the selected appliance switches on.

If the left button is pressed, the selected appliance switches off again.

3. INSTALLATION

BATTERY INSTALLATION

Install the enclosed battery in the remote control as follows (fig. 1) :

Open the battery case at the near the remote control.

Insert the battery in the unit, checking carefully that battery polarities (+ and -) match those inside the compartment.

INSTALLATION

Your appliances must be connected to the Power switches before you can control them with the remote control (fig. 2).

4. OPERATION

OPERATION

The connected appliances can now be operated via the remote control (fig. 3). The Power switches are operated with button 1,2,3 and all by default.


If the right button is pressed, the selected appliance switches on.

If the left button is pressed, the selected appliance switches off again.


The Power switches can also be operated with the last button of the remote control.

This button is designed to operate more Power switches at the same time.

1



2



3

