

Operation Instructions

1. **Inserting the battery:** Open the battery compartment on the back of the figure with a screwdriver. Lift off the door. Using the battery connector inside the compartment, snap in a 9-volt battery. Put the battery in the compartment and replace the battery door.
2. **To turn the walkie talkie on:** Move the ON/OFF switch located on the back of the figure to the ON position. You will hear a low hissing background noise, which indicates the unit is working properly.
3. **To transmit to any compatible walkie talkie:** Push the TALK button on the left side of the unit. Hold it down while you speak into the speaker/microphone located in the chest of the figure.
4. **To listen to another person talking on another unit:** Release the TALK button and wait to hear their voice. You must release the TALK button to hear any other transmission.
5. **To use MORSE CODE features:** You must hold down the TALK button while you press the MORSE CODE button located on the front of the figure. You can press the MORSE CODE button in the sequences shown on the Morse Code Chart.
6. **To turn the walkie talkie off :** Move the ON/OFF switch to the OFF position. This maintains the battery life.

Battery Use Instructions

Non-rechargeable batteries are not to be recharged.
 Exhausted batteries are to be removed from the toy.
 The supply terminals are not to be short-circuited.
 Do not mix old and new batteries.
 Do not mix alkaline, standard (Carbon-zinc) or rechargeable (Nickel Cadmium) batteries.
 Only batteries of the same or equivalent type as recommended are to be used.
 Batteries are to be inserted with the correct polarity.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- Consult the dealer or an experienced radio/TV technician for help.