

## HZ5000 RF Wireless Optical Mouse User's Guide

1. Insert the batteries into the mouse. Ensure that the batteries are installed correctly and that the (+) & (-) are correct.
2. Turn OFF the computer.
3. Plug in your USB or PS2 receiver into the USB or PS2 port and restart the computer.
4. Press the ID switch on the receiver for 3 seconds.
5. You should see a red light flashing when the mouse is moved. It means that the mouse and the receiver are communicating successfully.
6. If you don't see a red light flashing or if the mouse is not responding, you may need to remove the previous mouse driver(s) and restart the computer, and repeat Step 4&5.
7. Once Windows is restarted, it will find new hardware and install the correct driver you need to make your mouse function properly.
8. If the scrolling is not working but the mouse is, you may need to go to the add/remove programs in your control panel and remove any previous mouse software that may be installed on your computer and restart the computer again.

**IMPORTANT:** When doing ID setting users need to follow the instruction bellow,

- a. Distance between mouse and receiver cannot be more than 0.5 meter.
- b. Users need to press both ID switch within 5 seconds in order to complete ID setting.
- c. When charging batteries, users need to repeat Step 4&5.

### **Warning:**

Changes or modifications to this unit not expressly approved by the party responsible for compliance will void the user's authority to operate the equipment. Any change to the equipment will void FCC grant.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.