

## Code Erasing & Memorizing & Shut down the alarm sound

memorized

## Button & Function

outdoor alarm

You can possess two pieces of "KeynoKey" remote to the maximum. In case of stolen or missing your "KeynoKey" remote, you should immediately erase your code.

### How to memorize your code:


>> Please press button#1 for 3 seconds which activating remote.

>> Please insert your car key into cylinder and open driver side door.

>> Please repeat your car key five times over between "ACC" and "ON" position within 10 seconds.

>> Please press button#2 for 1 second after hearing a chirp sounds. (This must be done within 5 second)

>> Your code memorizing is completed if chirp sound come two times.



### How to erase your code:

>> Please insert your car key into cylinder and open driver side door.

>> Please repeat your car key five times over between "ACC" and "ON" position within 10 seconds.


>> Please wait for 5 seconds after hearing a chirp sound.

>> Please insert your car key into cylinder and open driver side door.


>> Firstly, please shut down the alarm sound with "KeynoKey" remote.

>> Secondly, press button #1(door unlock) or press button#2 (Temporary system-off)

Button	Time	Function
Button1	1sec	Compulsory unlock long-range
Button2	2sec	Car finder
	1sec	Temporary function stop
Distant adjustment switch	2sec	Mute
		LONG-MID-SHORT



## Wire Diagram



- If horn is (+), siren is additionally required.

- (-) door pin : Door open "Voltage : Low", Door close "Voltage : High".

- (+) door pin : Door open "Voltage : High", Door close "Voltage : Low".

Information to user : PART 15, PARAGRAPH 15.21 AND

15.105(b)

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

FCC Notice

NOTE : This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.