

RHINOS + WALKIE-TALKIE

RUGGED WATERPROOF WIRELESS

HEAD-PHONES

Product Name:Bluetooth headphone











Good call on picking up the Outdoor Tech. Rhinos wireless headphones. Your experience of the universe will soon he enhanced. This manual exists to help make sure that you use them correctly, so you're definitely going to want to relax for a hot second and look through this.

Kisses.



OUTDOOR TECH.

CONTENTS

Anatomy	
Controls	
Power Up	
Pairing	
Walkie-Talkie App	
Talk	7
Sners	R

ANATOMY




Walkie-Talkie Function Button

Record Voice Message

1

ANATOMY (CONTINUED)



CONTROLS

RIGHT EAR PIECE

FUNCTION	BUTTON	ACTION
Power on	€	Press 2 seconds
Power off	€	Press 3 seconds
Manual pairing mode	+-	Press + and – for 3 seconds
Play / Pause	€	Short press once
Volume up	+	Short press once
Volume down	_	Short press once
Skip forward	>>	Short press once
Skip backward	«	Short press once
Voice Dial/Siri/ Google	(f)	Double press MFB button

LEFT EAR PIECE

FUNCTION	BUTTON	ACTION
Record message	Ø	Press and hold Walkie- Talkie button
End recording	€	Release Walkie-Talkie button

POWER UP



For best results, fully charge your Rhinosm using the supplied micro sub charge cable before use.

You can manage/check your Rhinos battery by the fuel gauge that appears on your iOS device.

Low Battery

There will be one voice prompt stating "battery low" and the LED will flash 1 time.

Critically Low Battery

There will be one voice prompt stating "charge me" and the LED will flash 1 time.

Once the Rhinos are plugged into the micro-USB, the indicator light will turn red. It will turn off once the Rhinos™ are completely charged.

PAIRING

Pairing your Rhinos

Power on. Long press MFB for 2 seconds. The blue LED flashes 3 times. Voice prompts "power on". Rhinos will enter pairing mode. Voice prompts "pairing".

Select (ODT Rhinos) from the list of bluetooth devices on your phone.

To Enter Pairing Mode Manually

To enter pairing mode manually.
Press "+" button and "-" button at the
same time for 3 seconds. The red and
blue light alternatively flashes.



Pairing Success

Voice prompts "paired". The red and blue light stop flashing alternatively.

CONNECT TO THE WALKIE-TALKIE APP



Once you have turned on and paired your Rhinos to your smartphone, you will be able to connect to the Walkie-Talkie App. (Hooray!!)

STEP 1: Pair Rhinos to device

STEP 2: Go to www.outdoortech.com/apps

STEP 3: Download app and follow app instructions.

Yes... It is that easy.

TALK



The following are tips on how to use your Rhinos™ to speak on the telephone:

Answer a call Short press MFB

Volume up Short press + Volume down Short press -

Voice dial/siri/google...... Double press MFB button

SPECS



Charging Timeapprox. 3hrs
Wearing Styleon-ear
Product Dimensions 197*170*82mm
Charge Cable Length 350mm
Speaker Size40mm
Speaker Sensitivity128±3dB
Speaker Impedance 32 OHM
Speaker Max Input Power30 MW
Speaker Frequency Range 100HZ~3KHZ
Microphone Type Condenser Microphone
Microphone Frequency Range70~10KHZ
Microphone Sensitivity45~-39 dB
Charge InputMicro USB DC/5V 0.5A
Certification(s) FCC, CE, IC, RoHS, IPX6
Warranty 1 Year limited warranty



DON'T BE SO ANTISOCIAL







Facebook.com/outdoortechnology Twitter & Instagram: @outdoortech

Questions, comments, complaints, secret desires, or just to say what's up: email info@outdoortech.com

K bye.



Caution-

This device complies with Part 15 of the FCC Rules / Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference will not occur in a particular installation. If this equipment does cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other uses, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication. Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (o.i.e.) ne dépasse pas l'intentisé nécessaire à l'établissement d'une communication

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

(1) This device may not cause interference; and

satisfaisante

(2) This device must accept any interference, including interference that may cause undesired operation of the device.