

Sound Bar
Barre de son

Reference Guide	GB
Guide de référence	FR
Guía de referencia	ES

https://rd1.sony.net/help/ht/2079/h_zz/

©2022 Sony Corporation
Printed in China
Imprimé en Chine
https://www.sony.net/



HT-S2000

Model, Modèle, Modelo: YY2079C

English

Before using the unit, be sure to read the End User License Agreement (EULA) supplied with the unit. The content of the agreement also applies to speakers (available separately) connected to the unit (unless those speakers have a separate license agreement).

Model: YY2079C

The term "product" in this document refers to the unit or its accessories.

Owner's Record

Record the serial number in the space provided below. Refer to them whenever you call upon your Sony service center.

Model No. HT-S2000

Serial No. _____

The model and serial numbers are located on the following:

- the bottom of the unit

Do not install the product in a confined space, such as a bookcase or built-in cabinet.

To reduce the risk of fire, do not cover the ventilation opening of the unit with newspapers, tablecloths, curtains, etc. Do not expose the unit to naked flame sources (for example, lit candles).

To reduce the risk of fire or electric shock, do not expose this product to dripping or splashing, and do not place objects containing liquids, such as vases, on top of the product.

The AC adaptor is not disconnected from the AC power source (mains) as long as it is connected to the wall outlet, even if the unit itself has been turned off.

As the main plug of the AC adaptor is used to disconnect the AC adaptor from the mains, connect it to an easily accessible AC outlet. Should you notice an abnormality in it, disconnect it from the AC outlet immediately.

For Remote Commander

CAUTION: Danger of explosion if battery is replaced by an incorrect type.

Dispose of used batteries according to the instructions.

Do not expose the batteries (battery pack or batteries installed) to excessive heat, such as sunshine, fire or the like for a long time.

This product (including accessories) has magnet(s) which may interfere with pacemakers, programmable shunt valves for hydrocephalus treatment, or other medical devices. Do not place this product close to persons who use such medical devices. Consult your doctor before using this product if you use any such medical device.

The nameplate and important information concerning safety are displayed on the bottom of the unit.

For customers in the U.S.A.

NOTE:

This unit has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This unit generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this unit does cause harmful interference to radio or television reception, which can be determined by turning the unit off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the unit and receiver.
- Connect the unit and antenna on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Proper shielding and ground connections must be used for connection to host computers and/or peripherals in order to meet FCC emission limits.

The device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

If you have any questions about this product, visit <http://www.sony.com/electronics/support>.

Write: Sony Customer Information Service Center 12451 Gateway Blvd., Fort Myers, FL 33913

Supplier's Declaration of Conformity

Trade Name: 'SONY'

Responsible Party: Sony Electronics Inc.

Address: 16535 Via Espriilo, San Diego, CA 92127 U.S.A.

Telephone Number: 858-942-2230

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this unit.

This unit must not be co-located or operated in conjunction with any other antenna or transmitter.

The unit complies with FCC radiation exposure limits set forth for an uncontrolled environment and meets FCC radio frequency (RF) Exposure Guidelines. This unit should be installed and operated keeping the radiator at least 20 cm or more away from person's body.

Compliance with FCC requirement 15.207(a)

Data transmission is always initiated by software, which is passed down through the MAC, through the digital and analog baseband, and finally to the RF chip. Several special packets are initiated by the MAC. These are the only ways the digital baseband portion will turn on the RF transmitter, which it then turns off at the same packet. Therefore, the transmitter will be on only when one of the aforementioned packets is being transmitted. In other words, this unit will automatically discontinue transmission in case of either absence of information to transmit or operational failure.

Frequency Tolerance: $\pm 20\text{ ppm}$

For customers in Canada

This unit contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This unit may not cause interference; and
- (2) This unit must accept any interference, including interference that may cause undesired operation of the unit.

This unit complies with ICES radiation exposure limits set forth for an uncontrolled environment and meets ICES-102 of the ICES radio frequency (RF) Exposure Guidelines. This unit should be installed and operated keeping the radiator at least 20 cm or more away from person's body.

5.150 MHz - 5.350 MHz band is restricted to indoor operations only.

Data transmission is always initiated by software, which is passed down through the MAC, through the digital and analog baseband, and finally to the RF chip. Several special packets are initiated by the MAC. These are the only ways the digital baseband portion will turn on the RF transmitter, which it then turns off at the same packet. Therefore, the transmitter will be on only when one of the aforementioned packets is being transmitted. In other words, this unit will automatically discontinue transmission in case of either absence of information to transmit or operational failure.

About recommended cables

Properly shielded and grounded cables and connectors must be used for connection to host computers and/or peripherals.

Mounting the Bar Speaker on a Wall

• Prepare screws (not supplied) that are suitable for the wall material and stability. Depending on the wall material, the wall may be damaged.

• Fasten the screws securely in the wall beam.

• Hang the bar speaker on the reinforced wall.

• Have the installation done by a Sony dealer or licensed contractor and pay special attention to safety during the installation.

• Sony shall not be held responsible for accidents or damage caused by improper installation, insufficient wall stability, improper screw installation, natural disasters, etc.

• Two or more persons are required to hang the bar speaker for safety.

1 Prepare two screws (not supplied) that are suitable for the wall mount holes on the rear of the bar speaker.

2 Align the vertical line above the *② TV CENTER LINE* printed on the WALL MOUNT TEMPLATE (supplied) with the center of the width of your TV.

Center of the TV

TV CENTER LINE


Adhesive tape, etc.

WALL MOUNT TEMPLATE

TV BOTTOM LINE

3 Align the *② TV BOTTOM LINE* printed on the WALL MOUNT TEMPLATE with the bottom of your TV, then adhere the WALL MOUNT TEMPLATE on the wall with a commercially available adhesive tape, etc.

4 Fasten the screws prepared in step 1 securely into the screw marks on the *② SCREW LINE* printed on the WALL MOUNT TEMPLATE.




Français

Español

Dolby Atmos

dts x



- Fasten the screws prepared in step 1 securely into the screw marks on the *② SCREW LINE* printed on the WALL MOUNT TEMPLATE.
- Remove the WALL MOUNT TEMPLATE.
- Connect cables to the bar speaker.


① Connect the HDMI cable (supplied) to the HDMI OUT (TV eARC/ARC) jack on the bar speaker.

② Connect the AC adaptor (supplied) to the DC IN terminal on the bar speaker and then the AC power cord (mains lead) (supplied) to the AC adaptor.

Note

- If your TV is not equipped with eARC or eARC, connect the optical digital cable (not supplied) instead of the HDMI cable (supplied).
- For TV connections, refer to Help Topics.

7 Hang the bar speaker on the screws. Align the holes of the rear of the bar speaker with the screws, then hang the bar speaker on the two screws.



License

- Dolby, Dolby Atmos, Dolby Audio, and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation.
- Manufactured under license from Dolby Laboratories. Confidential unpublished works. Copyright © 1992–2021 Dolby Laboratories. All rights reserved.
- For DTS patents, see <http://patents.dts.com>.

Manufactured under license from DTS, Inc. DTS, DTS, DTS:X, and the DTS:X logo are registered trademarks and trademarks of DTS, Inc. in the United States and other countries. © 2022 DTS, Inc. ALL RIGHTS RESERVED.

This product is protected by certain intellectual property rights of Microsoft Corporation. Use or distribution of such technology outside of this product is prohibited without a license from Microsoft or an authorized Microsoft licensee. Unlawful distribution of such technology is a violation of applicable law.

This product contains software that Sony uses under a licensing agreement with the owner of its copyright. We are obligated to announce the contents of the agreement to customers under requirement by the owner of copyright for the software. Please access the following URL and read the contents of the license.

<https://oss.sony.net/licenses/2022/>

The software included in this product contains copyrighted software that is licensed under the GPL/LGPL and other licenses which may require access to source code. You may find a copy of the relevant source code as required under the GPL/LGPL (and other licenses) at the following URL.

You may obtain the source code as required by the GPL/LGPL on a physical medium from us for a period of three years after our last shipment of this product by applying through the form at the following URL.

This offer is valid to anyone in receipt of this information.

<https://oss.sony.net/Products/Linux/>

Please note that Sony cannot answer or respond to any inquiries regarding the content of this source code.

Disclaimer regarding services offered by third parties

- Services offered by third parties may be changed, suspended, or terminated without prior notice. Sony does not bear any responsibility in these sorts of situations.

Precautions

- Before operating the unit, check that the operating voltage is identical to your local power supply. The operating voltage is indicated on the nameplate on the bottom of the unit.
- The supplied AC adaptor is designed exclusively for this unit. It should not be used in combination with any other devices.
- Completely disconnect the AC power cord (mains lead) from the AC outlet (mains) if it is not going to be used for an extended period of time. When unplugging the AC power cord (mains lead), always grip the plug. Never pull the cord itself.
- One blade of the plug is wider than the other for the purpose of safety and will fit into the wall outlet (mains) only one way. If you are unable to insert the plug fully into the outlet, contact your dealer.
- AC power cord (mains lead) must be changed only at a qualified service shop.

On placement

- Should any solid object or liquid fall into the unit, unplug the unit and have it checked by qualified personnel before operating it any further.
- Do not place the unit near heat sources or in a place subject to direct sunlight, excessive dust, or moisture or shock.
- The speakers of this unit are not of magnetically shielded type. Do not place magnetic cards on the unit or near it.
- Do not place metal objects other than a TV around the unit. Wireless functions may be unstable.
- Avoid letting the unit heats up during operation, this is not a malfunction.
- Place the unit in a location with adequate ventilation to prevent heat buildup and prolong the life of the unit.
- Use caution when placing the unit on a surface that has been specially treated (with wax, oil, polish, etc.), as staining or discoloration of the surface may result.

How to care for the unit

- Clean the unit with a soft, dry cloth. Do not use any type of abrasive pad, scouring powder, or solvent such as alcohol or benzene.

On BLUETOOTH® communications

- Microwaves emitting from a BLUETOOTH device may affect the operation of electronic medical devices. Turn off this unit and other BLUETOOTH devices in the following locations, as it may cause an accident:
 - in hospitals, near priority seating in trains, locations where inflammable gas is present, near automated doors, or near alarms.

Other notes

- You can enjoy new features and use the unit with more convenience and safety by updating the unit. For details, refer to Help Guide.
- Deactivating the auto standby function will increase the energy consumption of the product.
- When connecting the unit to the internet, use the router (ADSL modem or optical line termination device) with the connection supplied with the internet provider, or Wi-Fi access point. If you connect the unit to the internet without using the router, a security problem may occur. If you are not sure that the wall outlet for the network line has the router function, ask your manager of the apartment house or Internet provider.
- If you have any questions or problems concerning this unit that are not covered in this manual, please consult your nearest Sony dealer.

Trademarks

- Windows Media is either a registered trademark or trademark of Microsoft Corporation in the United States and/or other countries.
- The BLUETOOTH word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Sony Group Corporation and its subsidiaries is under license.
- The terms HDMI™, HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.
- All other trademarks and registered trademarks are trademarks or registered trademarks of their respective holders. In this manual, TM and ® marks are not specified.

Specifications

Sound Bar (HT-S2000)

Amplifier section

U.S. models:
POWER OUTPUT AND TOTAL HARMONIC DISTORTION: (FTC)

Front L + Front R: With 6 ohm loads, both channels driven, from 20 - 20kHz; rated 33 W per channel minimum RMS power, with more than 1% total harmonic distortion from 250 mW to rated output.

Canadian models:

POWER OUTPUT (rated):

Front L + Front R speaker blocks: 37 W + 37 W (at 6 ohms, 1 kHz) 1% THD

Center speaker block: 37 W + 37 W (at 6 ohms, 1 kHz) 1% THD

POWER OUTPUT (reference):

Front L/R + Rear R speaker blocks: 50 W (per channel at 6 ohms, 1 kHz)

Center speaker blocks: 50 W (at 6 ohms, 1 kHz)

