



RADIO CONTROL CAR OPERATING INSTRUCTIONS

- Put batteries in transmitter and car as shown in figure.
- Make sure all batteries are at the correct polarity.
- Turn the "ON/OFF" switch of the car to "ON" position. Then the car will act on Backward motion in circular path.
- Press the button on transmitter, the car will respond in going Straight Forward.
- To change the direction of car, just release the button; the car will act on Backward in circular path; until the head of the car face to the direction you want.
- Press the button, the car will go Forward in exactly the direction you want.
- Never store the car and transmitter with batteries inside. Used or dead batteries will be easy leaking harmful chemicals. It is better to remove all batteries from the car and transmitter if you are not going to use them.
- Do not use rechargeable batteries.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel cadmium) batteries.
- Non-rechargeable batteries are not to be recharged.
- Different types or new and used batteries are not mixed.
- Only batteries of the same or equivalent type as recommended are used.
- Batteries are inserted with correct polarity.
- Exhausted batteries are to be removed from the toys.



RADIO CONTROL CAR OPERATING INSTRUCTIONS

- Put batteries in transmitter and car as shown in figure.
- Make sure all batteries are at the correct polarity.
- Turn the "ON/OFF" switch of the car to "ON" position. Then the car will act on Backward motion in circular path.
- Press the button on transmitter, the car will respond in going Straight Forward.
- To change the direction of car, just release the button; the car will act on Backward in circular path; until the head of the car face to the direction you want.
- Press the button, the car will go Forward in exactly the direction you want.
- Never store the car and transmitter with batteries inside. Used or dead batteries will be easy leaking harmful chemicals. It is better to remove all batteries from the car and transmitter if you are not going to use them.
- Do not use rechargeable batteries.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel cadmium) batteries.
- Non-rechargeable batteries are not to be recharged.
- Different types or new and used batteries are not mixed.
- Only batteries of the same or equivalent type as recommended are used.
- Batteries are inserted with correct polarity.
- Exhausted batteries are to be removed from the toys.



INSTRUCTION TO THE USER

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

The user is cautioned that changes and modifications made to the equipment without the approval of manufacturer could void the user's authority to operate this equipment.