

How to assemble and install Link it





- To assemble Link it Reader and Cradle in vertical direction
- To connect Serial Port Cable Connector with Com 1 or Com 2 port of P.C
- ❖ To separate Connector of Keyboard from P.C.
- To connect Power Connector with Keyboard Port of P.C. and to connect Connector of Keyboard with the end of Power Connector.
- To insert Card into Link it Reader as shown in left side picture.
- To remove Card from Link it Reader with Link it Reader being fixed by hand.

Components of Link it

- Link it Reader
- Cradle
- ❖ RS-232C Cable and Power Cable
- User's Guide

Link it Power

❖ DC5V/100mA

Inquiry about Link it and A/S

Insis Co., Ltd. Tel.) 02-3421-0800 Fax.) 02-3421-0805 http://www.insis.net

Cautions

- To avoid installing "Link it" in humid or dusty or corrosive gas circumstances
- To keep Link it far away from fire.
- Do not give vibration or impact upon Link it
- Do brush the outside of Link it with dry rag, not with inflammable materials such as alcohol or benzene, etc.
- Do not dismantle Lint it at discretion as it's composed of electronic precision circuits.
- Be cautious not to infiltrate water or coffee into the inside of Link it..
- ❖ To call A/S center of Insis Co., Ltd. for any inquiry or breakdown.

FCC NOTICE

Caution :Any changes or modifications in construction of this device which are not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.