


INVISI-BUCK™ #2565

REMOTE CONTROLLED INVISI-BUCK™ ELECTRONIC DEER CALL

The "Invisi-Buck" is a break through in deer calling technology and the most innovative deer call on the market today. The "Invisi-Buck" will allow novice and first time hunters to call like a pro. No frills, just locate the "Invisi-Buck" in a strategic location, select the sound you want and push the button. Repeat as often as you like, choose from, Dominant Grunts, Doe Bleat, Antler Rattling, or the deadly Snort Wheeze.

INSTRUCTIONS



RECEIVER



TRANSMITTER

Your "Invisi-Buck" Remote Controlled Electronic Deer Call has a "Transmitter" and a "Receiver". The "Transmitter" will activate the "Receiver" from a distance of 150 feet. To operate, place the "Invisi-Buck" "Receiver" in a strategic, upwind location from your stand by using the enclosed adjustable strap. Place the "Receiver" approximately 2 to 3 feet off the ground for optimum sound performance. Turn "Receiver" on by moving switch down to the "On" position.

Caution: Turn "Receiver" off when not in use to extend battery life. At your stand location, push the desired button on your "Transmitter" to produce a two second sound of your choice. Choose from a "Snort-Wheeze", "Antler Rattle", "Dominant Grunt" or "Doe Bleat". Repeat sounds as often as you like or as your hunting situation dictates. Use multiple sounds to create a realistic hunting scenario. For example to produce a realistic "Buck Fight", press the "Snort-Wheeze" button one time and follow-up by pressing the "Antler Rattle" button three times in a row.

BATTERY INSTALLATION

Using a Phillips screw driver, unscrew the four small screws on the back of the "Receiver". Insert four AAA alkaline batteries. Be sure to match the positive and negative ends correctly. Replace cover.

To view other innovative Lohman products visit WWW.KOLPIN.COM

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

Lohman
Real Sound.

KOLPIN OUTDOORS, INC.

205 N. DEPOT STREET • P.O. BOX 107
FOX LAKE, WI 53933

Phone: (877) 9KOLPIN • Fax: (920) 928-3782
WWW.KOLPIN.COM

MADE IN CHINA



0 49464 32565 6

RECEIVED 16 FEB 2004