

# FLIP PHONE Walkie Talkies

## CAUTION:

1. Your transceiver set has been fully adjusted prior to shipment from the factory. Be sure not to touch the internal components other than replace batteries.
2. When the sound becomes weak, it is time to change the battery.
3. After use, always return the "ON/OFF" switch button to the "OFF" position.
4. Keep your set in a dry and clean place.

## HOW TO OPERATE YOUR TRANSCEIVER:


1. Open battery cover and snap in a 9-Volt battery.
2. Turn the "ON-OFF" button to the "ON" position. Your transceiver is now ready to operate.
3. Press the "PUSH-TO-TALK" button to transmit.
4. Release the "PUSH-TO-TALK" button to receive.
5. When transmitting, speak in a clear voice with the microphone about three inches (7.5 cm) from your mouth.
6. Best transmission and reception is achieved when the antenna is held in a vertical position.

## HOW TO USE MORSE CODE:

1. Switch the "ON-OFF" button to the "ON" position.
2. While pushing the "PUSH-TO-TALK" button, press in the "YES" button momentarily and release for desired signal length.
3. When back to voice communications again, use normal "PUSH-TO-TALK" operation.

## PRECAUTION:

Do not use rechargeable batteries.  
Keep unit away from extreme heat.



## Caution:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.




REQUIRES 2x9V  
BATTERIES  
(NOT INCLUDED)

For Product Questions  
Call 1-800-567-1774  
Ask for Customer Service  
Only in the US and Canada.

ITEM NO. 99112



J00925



**WARNING:**  
THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

Specifications are subject to change without notice.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.