

INSTRUCTION MANUAL FOR R/C CAR

Get ready:

1. Press the release button and open the clear cover.
2. Take out blister from the controller and obtain the antenna. Then unscrew the car from the blister to obtain the car. (see diagram #1/#2)
3. Secure the antenna with its end thread into the antenna hole on the controller.
4. Unscrew and remove the battery covers on both the controller and the charging unit. Insert 3 "AAA" batteries (not included) into the charger unit and 3 "AA" batteries (not included) into controller unit. Then replace the battery covers and tighten the screws (see diagram #4/#5)

Charging the car:


Place the car onto the charging holder tightly. The charging LED indicator will turn on when charging the car. The LED indicator will turn off when the car is fully charged.

- Remark: a). If the power of the batteries inside the controller are low or out, the LED light will become dim or off. And it cannot charge up the car. Replacement of new batteries is required.
- b). Ensure the orientation of car onto the charging holder is correct for charging. Both car and charging holder should match the same arrow ("↑") direction engraved on them. (see diagram #6)

Operating instruction:

1. Fully extend the antenna of the controller.
2. Press the forward and reverse buttons to make the car moves forwards and backwards respectively. For left and right turn, press the left and right buttons respectively. But the car will turn only when it is moving in forwards or backwards direction.
3. Occasionally the car will sway left or right while moving in forward or reverse direction. To correct this, adjust the directional guide on the bottom of car as shown in the illustration below. This may need to be done a few times while operating car. (see diagram #7)

- Remark: a). When operating the controller, please do not touch the antenna. Otherwise, the remote control distance and speed will both be reduced.
- b). If the speed of the car become slow, that means the charge-in power is almost used up. Recharge the car according to the aforesaid procedure.



This device complies with part 15 of the FCC rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference .
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications not approved by the party responsible for compliance could void user's authority to operate the device.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. This limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed, and used in accordance with the instruction, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ☐ Reorient or relocate the receiving antenna.
- ☐ Increase the separation between the equipment and receiver.
- ☐ Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- ☐ Consult the dealer or an experienced radio/TV technician for help.