



Test Setup Photo

Ant_311

Description: Radiated Spurious Emission Test Setup for Below 30MHz



Description: Radiated Spurious Emission Test Setup for Below 1GHz



Description: Radiated Spurious Emission Test Setup for Above 1GHz




Description: Radiated Spurious Emission Test Setup for Above 18GHz




Ant_312

Description: Radiated Spurious Emission Test Setup for Below 30MHz



Description: Radiated Spurious Emission Test Setup for Below 1GHz



Description: Radiated Spurious Emission Test Setup for Above 1GHz




Description: Radiated Spurious Emission Test Setup for Above 18GHz




Ant_340

Description: Radiated Spurious Emission Test Setup for Below 30MHz



Description: Radiated Spurious Emission Test Setup for Below 1GHz



Description: Radiated Spurious Emission Test Setup for Above 1GHz




Description: Radiated Spurious Emission Test Setup for Above 18GHz




Ant_348

Description: Radiated Spurious Emission Test Setup for Below 30MHz



Description: Radiated Spurious Emission Test Setup for Below 1GHz





Description: Radiated Spurious Emission Test Setup for Above 1GHz



Description: Radiated Spurious Emission Test Setup for Above 18GHz



Description: Test Setup for Conducted Emissions**Description: Test Setup for Conducted Emissions**

Description: Test Setup for Conducted Test**Description: Test Setup for DFS**