

Content

Safety Information

General Information

Your Speaker

Brief Introduction

Package and Accessories

How to Use

Charge it up
Bluetooth Connecting

Specifications

BLUETOOTH®

Problems and Solutions

Can't Find The BT Signal
Can't Pair With My Device
Re-dial Invalid


Safety Information

General Information

Do not expose your box to liquid ,moisture, humidity, Or rain
Do not use the box near the bathtub , sink , sauna, pool , or steam room. exposu re moisture could result in electronic shock .

Your BT Speaker

Brief Introduction



- ① Battery Indicator Light
- ② Charging Port
- ③ Audio-In Jack
- ④ Power Switch
- ⑤ BT Indicator Light
- ⑥ Volume Up/Next Track
- ⑦ Volume Down/Restart Track
- ⑧ Redial/Play/Stop/Talk
- ⑨ Mircophone

Package and Accessories

3.5mm AUX Cable x1
Micro USB Charging Cable x1
Instruction x1

How to Use

Charge it up

Before using your speaker for the first time , be sure to charge it up. Using the included cables, plug the Mircro-USB connector end in the charging port and the USB end into a wall charger or computer. A full charge takes approximately 3 hours .

USB Interface was for charging purpose only.

Bluetooth Connecting

- Simply turn the Power Switch on and the comes up ready to pair with your device. The Bluetooth Status Light will fl ash blue and orange. Ready to pair.
- Activate Bluetooth on the device you are pairing with (see your device's instruction manual for information on activating its Bluetooth settings).
- Go to the device's Bluetooth settings and select the speaker from the list.
- If asked for a passcode, enter 0000.
- You will hear 2 beeps and the Bluetooth Status Light will start flashing blue once every 3 seconds.

FCC RF Exposure Information and Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help