

## Remote Out-let function and spec <Rev 1.1>

### Specification -

**Operation Voltage** - Remote - DC - 2.2V - 3V , 1.5 AAA x 2 pcs

Remote Out-Let - AC - 120V +/- 20V

**Transmission Frequency** – 315 Mhz

**Distance** – 100 feet <+0 – 15feet> optional conditions

**Max control out-let** – 4 pcs

**Product size** – Remote – 140.5 <long> x 46 <wide> x 24.5 <thickness> mm

Remote Out-Let – 143.5 <long> x 60 <wide> x 61 <thickness with power pin> mm

### Product Function list –

#### Set Up –

1. install 2 pcs AAA alkaline batteries into remote control – Led blinking steadily until 4 digit code is entered. Example : 1 – 1 – 1 – 1
2. Plug in Remote Outlet into AC outlet, the Remote outlet Led blinking steadily then press a button of Remote Control.
3. Press the left side key from remote control to choose the number of Remote Outlet ( e.g.: 1,2,3 or 4 )
4. For set up the additional Remote outlet in same Remote control – simply follow step 2.
5. For set up the additional Remote control in same Remote outlet – simple follow step 1 in same code.

#### Operation -

1. To turn on the Remote outlet (thus any devise plugged in to it), press to corresponding On Key – left side of the Remote control.
2. To turn off the Remote outlet, press the corresponding Off Key – right side of the Remote control.
3. To turn On/Off all controlled Remote outlet by Remote control, press the “master” Key, On or Off.
4. To turn On/Off the Remote Outlet without the Remote control, briefly press the button on the remote outlet. Led will be On when Remote outlet is On.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

**Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.**

**NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.**

**However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:**

- Reorient or relocate the receiving antenna.**
- Increase the separation between the equipment and receiver.**
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.**
- Consult the dealer or an experienced radio/TV technician for help.**

**End**