

Safety Instructions

- Please follow the guides below to prevent unexpected accidents.

Warning—There is a possibility of a severe injury or death happening if you do not keep the instructions.

1. Do not extend or twist the power cable; a possibility of a fire or electric shock. Please contact a service center when electrical work is needed.
2. Only use an exclusive outlet and make sure the voltage designation of the DC adapter corresponds to the local electrical supply; a possibility of a fire or electric shock.
3. Never use your LCD monitor if the power cord has been damaged. Do not allow anything to rest on the power cord, and keep the cord away from areas where people can trip over it; a possibility of a fire or electric shock.
4. Do not use your LCD monitor in direct sunlight, and keep it away from the sources of heat; a possibility of a fire.
5. If your monitor does not operate normally— in particular, if there are unusual sounds or fumes coming out from it—unplug it immediately and contact a service center.
6. Never touch the plug with wet hands—a possibility of an electric shock.
7. Do not clean the front panel with inflammable materials such as benzene, gasoline, or thinner. Please clean the LCD monitor with a soft cloth; a possibility of panel damage.

Caution—There is a possibility of a slight injury or product damage happening if you do not keep the instructions.

1. To avoid electric shock, never touch the inside of the LCD monitor. Only a qualified technician should open the case of the LCD monitor.
2. Never scratch the LCD panel or insert anything into the cabinet openings of the LCD monitor; a possibility of a fire, electric shock, or monitor damage.
3. Unplug the LCD monitor when it is going to be left unused for an extended period of time; a possibility of an unexpected accident.

4. Put your LCD monitor in a location with low humidity and a minimum of dust
5. Be cautious not to block the ventilation openings with a curtain or table cloth; a possibility of a fire caused by a rise of inner temperature.
6. Put the LCD monitor apart from a wall about 10cm; a possibility of a fire caused by a rise of inner temperature.
7. Be sure to hold the plug, not the cord, when disconnecting the LCD monitor from an electric socket; a possibility of wire snapping and being an origin of a fire.
8. Unplug your LCD monitor from the AC outlet before any service.