




ANNEX 1 – EXTERNAL PHOTOGRAPHS OF EQUIPMENT UNDER (Transmitter & Antenna Units) Photo #1
Pulse Ekko Pro (50 MHz, 100 MHz and 200 MHz), Model No.: TLF-A **FCC ID: QJQ-PE-PRO-TLF-A**



ANNEX 1 – EXTERNAL PHOTOGRAPHS OF EQUIPMENT UNDER (Transmitter & Antenna Units) Photo #2
Pulse Ekko Pro (50 MHz, 100 MHz and 200 MHz), Model No.: TLF-A **FCC ID: QJQ-PE-PRO-TLF-A**





ANNEX 1 – EXTERNAL PHOTOGRAPHS OF EQUIPMENT UNDER (Transmitter & Antenna Units) Photo #3
Pulse Ekko Pro (50 MHz, 100 MHz and 200 MHz), Model No.: TLF-A FCC ID: QJQ-PE-PRO-TLF-A
Pulse Ekko Pro with 200 MHz Antenna





ANNEX 1 – EXTERNAL PHOTOGRAPHS OF EQUIPMENT UNDER (Transmitter & Antenna Units) Photo #5
Pulse Ekko Pro (50 MHz, 100 MHz and 200 MHz), Model No.: TLF-A FCC ID: QJQ-PE-PRO-TLF-A
Pulse Ekko Pro with 100 MHz Antenna






ANNEX 1 – EXTERNAL PHOTOGRAPHS OF EQUIPMENT UNDER (Transmitter & Antenna Units) Photo #7
Pulse Ekko Pro (50 MHz, 100 MHz and 200 MHz), Model No.: TLF-A FCC ID: QJQ-PE-PRO-TLF-A
Pulse Ekko Pro with 50 MHz Antenna



ANNEX 1 – EXTERNAL PHOTOGRAPHS OF EQUIPMENT UNDER (Transmitter & Antenna Units) Photo #8
Pulse Ekko Pro (50 MHz, 100 MHz and 200 MHz), Model No.: TLF-A FCC ID: QJQ-PE-PRO-TLF-A



View of connector on bottom of transmitter



View of connector on antenna.

