

INSTRUCTION MANUAL

DANGER:ELECTRICAL REMOTE CONTROL SOCKET CAN BE HAZARDOUS

* Misuse Can RESULT In FIRE or DEATH by ELECTRICAL SHOCK

Please READ BOTH SIDES Carefully and Follow All Directions.

BEFORE USE

*.Use Only With Christmas decorative lighting, and Other Seasonal-Use Lighting products.

*.For Temporary Use Only (Not to Exceed 90 Days).

* **FOR INDOOR USE ONLY.**

*.Inspect Thoroughly Before Each Use. **DO NOT USE IF DAMAGED.**

*.This Remote Control Socket is Rated 5 Amps max..

DURING USE

*.keep Away From Water.

* **DO NOT USE WHEN WET.**

*.Keep children and pets Away From Remote control socket.

AFTER USE

. * **GRASP PLUG** to Remove From Outlet.

. * Always Unplug When Not In Use.

DO NOT REMOVE THIS TAG

CAUTION

-This Remote Control set is for use with Christmas decorative lighting sets only.

-This Remote Control set is Rated 5 Amps max.

-Made in China

FCC ID: QKZPLTRC5M

MADE IN CHINA

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

“Modifications not authorized by the manufacturer may void users authority to operate this device”

NOTE:

This equipment has been tested and found to comply with limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.