

*** USER'S MANUAL ***

FCC ID : QUYMODULEWH01

The Federal Communication Commission Statement

This equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of more of the following measures: -

- **Reorient or relocate the receiving antenna.**
- **Increase the separation between the equipment and receiver.**
- **Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.**
- **Consult the dealer or an experienced Radio/TV technician for help.**

Use only shielded cables to connect I/O devices to this equipment. You are cautioned that change or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

THIS DEVICE COMPLIES WITH PART 15 OF FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

- 1 This device may not cause harmful interference and
- 2 This device must accept any interference received, including interference that may cause undesired operation.

The antenna used for this transmitter must not be collocated or operation in conjunction with any other antenna or transmitter.

Notice : The changes or modifications not expressly approved by the party responsible for compliance could void the user' s authority to operate the equipment.

IMPORTANT NOTE: To comply with the FCC RF exposure compliance requirements, no change to the antenna or the device is permitted. Any change to the antenna or the device could result in the device exceeding the RF exposure requirements and void user' s authority to operate the device.



User Manual
For
Android
Rev. 0.9

Section 1 Getting Start - Download WiFi Huber App

1. Download App from Google play

1. 開啟 [play 商店] 程式，進入商店主畫面



Pic 1.


You can use the Keyword **WiFiHuber**, to search the WiFiHuber App, then download & install it..

Section 2 Connect WiFi

The major step to connect WiFi Huber, is similar as general AP router, you can search SSID from smart handheld device's setup App. The operation step is as following:

Select the Setup App icon to enable setup App, as the following Pic 2

2.按手機主畫面的 [設定]



Pict 2

3. Choose the WiFi & Internet item, as Pic 3
3. 開啟 無線與網路



Pic 3

Select Wi-Fi setup item, you need to enable Wi-Fi function and then to select SSID, WiFiHuber.

When you choose the WiFiHuber SSID, you will see the negotiation process, your smart handheld device will get IP address from WiFiHuber device, then it will see the connected status, if it is successful. Reference Pic 4.

4. 再開啟 Wi-Fi 設定，選擇要連接的網路，之後再按返回鍵回手機主頁



Pic. 4

Section 3 Enable App


If you had successfully installed the App, then you will see the WiFiHuber App ICON as following:



Pic 5


Touch the App, then you can enable the WiFiHuber.

Welcome to WiFi Huber, if you enable the App, then you will see the main frame as Pic 6




Pic 6

In Green rectangle box, you will see the storage device's label in upper side, and you also can fine the 5 function pages as following:




: It is a WiFiHuber storage icon, when you select the function page, then you can operate the file/directory. If you touch the

1. Directory: You can enter the directory and we can display the contain.
2. File: if the file's contain is supported, for example, general JPG photo file, then you can get the picture on the screen.




Pic 7



: It is a handheld device local file operation function page. When you apply the function, you will see the file/direct with your device.

The WiFiHuber provide friendly function, the general popular file sorting function. It can automatically sort the WiFi storage, including, Audio, Video and Photo. User, he or she can get those service by the following function page.




: User can get all of the supported audio file format file stored within WiFi Storage when she or he touch the ICON, as in following Pic 8.




Pic 8

As the Pic 8, if you can select the file, the you can play the music as the following Pic 9.



Pic 9.




: We also support sorted photo function, when you touch the Photo Icon, you can get the all supported photo file as Pic 10.




Pic 10.


You can touch the file, then you can get the photo as following:



Pic 11.



: For Video sorted file function, when you touch the Video function Icon, user can get all of supported video files with WiFi Storage, as Pic 12.



Pic 12.

Again, when you touch the file, you can start playing the video.



Pic 13