















# INSTRUCTIONS

ITEM NO. 0815





**HOBBYENGINE EMAIL ADDRESS:info@hobbyengine.com.hk**



# Attention!

## Important Information About Your 7.2V Ni-Mh Rechargeable Battery

1. Do not charge the battery over 5.5 hours, as this reduces the life of the battery
2. Do not leave the battery unattended while charging.
3. When you feel the speed/motion of the R/C vehicle decrease or stop under normal operation, stop running the R/C vehicle and charge the Rechargeable Battery for no more than 5.5 hours.
4. For best performance of the battery, do not charge the Rechargeable Battery when the battery is still operating sufficiently in the vehicle. It is best to completely drain the battery before recharging.

NOTE: CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.