

<p>English DAC and Headphone Amplifier</p> <p>Buttons and Ports Labeled</p> <p>• Charging The device has two USB ports, both of which support PD fast charging and regular 5V power charging. The port marked with "USB" supports PD fast charging. When charging the battery through it, please set both the "Phone mode switch" and "Desktop mode switch" to OFF. When charging the battery through it, please set the "Desktop mode switch" to OFF.</p> <p>• PHONE MODE After connecting to a mobile phone for decoding, the device provides an option of whether to consume the battery of the phone or not. When the "Phone mode switch" is set to "ON", the device will not consume the phone's battery. When the switch is set to "OFF", the phone will charge the device instead.</p> <p>• DESKTOP MODE The device supports a desktop mode. When the "Desktop mode switch" is set to "ON", the device can be used as a desktop decoder. In this mode, the battery of the device will not be charged. When the switch is set to "OFF", the desktop mode will be disabled.</p> <p>• Instructions for the Volume Knob 1. Working mode switching: On the homepage, short press the volume knob to enter the working mode menu. Rotate the knob to successively switch between "USB" - "COAXIAL" - "BLUETOOTH" modes. Short press the volume knob for confirmation. Long press the volume knob to return to the homepage. 2. Setting mode: On the homepage, long press the volume knob to call up the settings menu. Rotate the knob to switch between different settings and short press it for confirmation. Long press the volume knob for about 2s to return to the previous page. 3. Volume adjusting: On the homepage, rotate the volume knob to turn the volume up and down.</p> <p>• Working Modes The device supports 3 working modes: 1. USB: USB decoding, connect to mobile phones or computers via USB for decoding; 2. COAXIAL: Coaxial decoding, connect to devices with a coaxial output; 3. BLUETOOTH: Bluetooth decoding, connect to devices that support Bluetooth output.</p> <p>• Turn on/off When the device is off, long press the "Power/Lock" button to turn it on. When it is on, long press the "Power/Lock" button to turn it off. When it is on, short press the "Power/Lock" button to wake up/turn off the display.</p>	<p>English DAC and Headphone Amplifier</p> <p>• Charging The device has two USB ports, both of which support PD fast charging and regular 5V power charging. The port marked with "USB" supports PD fast charging. When charging the battery through it, please set both the "Phone mode switch" and "Desktop mode switch" to OFF. When charging the battery through it, please set the "Desktop mode switch" to OFF.</p> <p>• PHONE MODE After connecting to a mobile phone for decoding, the device provides an option of whether to consume the battery of the phone or not. When the "Phone mode switch" is set to "ON", the device will not consume the phone's battery. When the switch is set to "OFF", the phone will charge the device instead.</p> <p>• DESKTOP MODE The device supports a desktop mode. When the "Desktop mode switch" is set to "ON", the device can be used as a desktop decoder. In this mode, the battery of the device will not be charged. When the switch is set to "OFF", the desktop mode will be disabled.</p> <p>• Instructions for the Volume Knob 1. Working mode switching: On the homepage, short press the volume knob to enter the working mode menu. Rotate the knob to successively switch between "USB" - "COAXIAL" - "BLUETOOTH" modes. Short press the volume knob for confirmation. Long press the volume knob to return to the homepage. 2. Setting mode: On the homepage, long press the volume knob to call up the settings menu. Rotate the knob to switch between different settings and short press it for confirmation. Long press the volume knob for about 2s to return to the previous page. 3. Volume adjusting: On the homepage, rotate the volume knob to turn the volume up and down.</p> <p>• Working Modes The device supports 3 working modes: 1. USB: USB decoding, connect to mobile phones or computers via USB for decoding; 2. COAXIAL: Coaxial decoding, connect to devices with a coaxial output; 3. BLUETOOTH: Bluetooth decoding, connect to devices that support Bluetooth output.</p> <p>• Turn on/off When the device is off, long press the "Power/Lock" button to turn it on. When it is on, long press the "Power/Lock" button to turn it off. When it is on, short press the "Power/Lock" button to wake up/turn off the display.</p>	<p>English DAC and Headphone Amplifier</p> <p>3. BLUETOOTH: Bluetooth decoding, connect to devices that support Bluetooth output. When switched to the Bluetooth receiving mode for the first time, the device will automatically enter the pairing state. At this time, the screen of the device will display "Pairing...". In later uses when entering the Bluetooth receiving mode, the device will automatically reconnect to the last-connected device. Note: The device does not support voice calls through Bluetooth.</p> <p>In Bluetooth decoding mode, the button functions are as follows: -Force into pairing mode: Long press the Play/Pause button for about 3s; -Manual reconnect: Short press the Play/Pause button when the device is disconnected; -Clear pairing: Long press the Previous track/Next track buttons for about 3s at the same time; -Play/Pause: Short press the Play/Pause button; -Previous track/Next track: Short press the Previous track/Next track button.</p> <p>• DESKTOP MODE The device supports a desktop mode. When the "Desktop mode switch" is set to "ON", the device can be used as a desktop decoder. In this mode, the battery of the device will not be charged. When the switch is set to "OFF", the desktop mode will be disabled.</p> <p>• Instructions for the Volume Knob 1. Working mode switching: On the homepage, short press the volume knob to enter the working mode menu. Rotate the knob to successively switch between "USB" - "COAXIAL" - "BLUETOOTH" modes. Short press the volume knob for confirmation. Long press the volume knob to return to the homepage. 2. Setting mode: On the homepage, long press the volume knob to call up the settings menu. Rotate the knob to switch between different settings and short press it for confirmation. Long press the volume knob for about 2s to return to the previous page. 3. Volume adjusting: On the homepage, rotate the volume knob to turn the volume up and down.</p> <p>• Working Modes The device supports 3 working modes: 1. USB: USB decoding, connect to mobile phones or computers via USB for decoding; 2. COAXIAL: Coaxial decoding, connect to devices with a coaxial output; 3. BLUETOOTH: Bluetooth decoding, connect to devices that support Bluetooth output.</p> <p>• Turn on/off When the device is off, long press the "Power/Lock" button to turn it on. When it is on, long press the "Power/Lock" button to turn it off. When it is on, short press the "Power/Lock" button to wake up/turn off the display.</p> <p>Learn more</p> <ul style="list-style-type: none"> For related video instructions of the Q15 and FAQ (Frequently Asked Questions), please scan the QR code below. To learn more about the product, please visit our website: www.fio.com The Q15 can be controlled by the FIO Control App. Please scan the QR code below to download the app. <p>Notes and Precautions</p> <p>• Please do not expose the battery in a high-temperature environment. The battery is prone to overheating and may catch fire if it is exposed to water, or if it gets swollen. Please do not disassemble, hit, crush, or puncture the battery, and do not put it on fire.</p> <p>• Please do not place the device in circumstances of excessive high/low temperatures (above 45°C or below 0°C), or in an enclosed high-temperature environment, such as in a car.</p> <p>• Please do not repair or disassemble the product on your own and do not put it near water.</p> <p>• Please charge the battery on a regular basis to secure the battery life if this product has not been used for a long time.</p> <p>• You might not be able to hear the sound of the surroundings when using headphones. For your safety, please avoid using headphones in dangerous situations.</p> <p>• It is recommended to use a suitable charger in case of a high-voltage adapter causing damage to the device.</p> <p>• In the likely event that the Q15 hangs up, please try to hold the power button for about 10s to reset it.</p> <p>WEEE Directive & Product Disposal</p> <p>• At the end of its serviceable life, this product should not be handled as household or general waste. It should be handed over to the applicable collection point for the recycling of electrical and electronic equipment, or returned to the supplier for disposal.</p> <p>Internal/Supplied Batteries</p> <p>This symbol on the product indicates that the battery is to be collected separately. This battery is designed for separate collection at an appropriate collection point. Qualcomm is a trademark of Qualcomm Incorporated, registered in the United States and other countries. aptX is a trademark of Qualcomm Technologies International, Ltd., registered in the United States and other countries.</p> <p>CE</p> <table border="1"> <thead> <tr> <th>Function</th> <th>Frequency</th> <th>Maximum output power</th> </tr> </thead> <tbody> <tr> <td>Bluetooth</td> <td>2402-2480MHz</td> <td>7.1dBm</td> </tr> </tbody> </table> <p>CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.</p> <p>This product can be used in Europe without restrictions.</p> <p>FCC NOTICE:</p> <p>This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -- Consult the dealer or an experienced radio/TV technician for help.</p> <p>Qualcomm aptX HD</p>	Function	Frequency	Maximum output power	Bluetooth	2402-2480MHz	7.1dBm
Function	Frequency	Maximum output power						
Bluetooth	2402-2480MHz	7.1dBm						