
Yourioon[®]

Bluetooth Speaker



User Guide YM-Z38

Safety Instructions

Read this manual carefully before putting the appliance into operation and keep this manual for future reference.

- Do not insert any metal object into the device.
- To avoid a static charge, do not use the device in an extremely dry climate.
- · Do not attempt to repair the device yourself.
- Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like

In the Box



A Bluetooth Speaker USB charging cable







Warranty card


Specifications

Bluetooth version	3.0	
Bluetooth profiles	HSP, HFP, A2DP and AVRCP	
Bluetooth operating distance	10 meters (equal to 33 feet)	
Output power	5wX2	
Frequency response	100Hz-20kHz	
Distortion	≤ 1%	
Microphonesensitivity	-40db	
Playback time	Music time 6 hours, talk time 8 hours	
Charging input power	DC 5V	
Charging time	Approx3 hours	
Unit INCH	6.3*2.4*1.6 INCH	

Features

- · Bluetooth 3.0, high speed and low power consumption.
- · Built in rechargeable lithium battery.
- · Built in microphone for hands free phone calls.
- · Support TF card playback.
- · AUX in function for non-bluetooth devices.

Location of Controls



l		
l	1	Power on/off.
l	2	Play/Pause/Mode button
l	3	Next
l	4	Vol+
l	(5)	Phone button
l	6	PREV
l	7	Vol-
l	8	Aux jack
ı	9	DC 5V charging port
ı	10	TF card slot

Pairing the Bluetooth Speaker

- 1.Press and hold the Power on/off button until you hear a tone, the Bluetooth status LED will flash red and blue, indicating that the Bluetooth speaker is in pairing mode.
- 2.Set your Bluetooth-enabled device to search for Bluetooth devices.
- 3. When the Bluetooth-enabled device finds the Bluetooth speaker, select "YM-Z38" from the list of found devices.
- 4. After a successful pairing, a beep tone will be heard indicating that the device is paired and the Bluetooth status LED will stay solid blue.
- If a previously paired device is in range when the Bluetooth speaker is turned on, the Bluetooth speaker will connect to it automatically.





The screenshots above are typical of many Bluetooth-ebabled devices in the market today, and are used to assist in the explanation of the pairing process. Your Bluetooth-enabled devices's interface and interaction with the Bluetooth Speaker may differ slightlyfrom the illustrations slightly above.

Using the Bluetooth Speaker

Powering ON/OFF

 Press and hold the O button for about 3 seconds. Play/Pause/Mode button

• Qucik press No button to play or pause music. Press and hold NO button for about 3 seconds to switch between Switch between Bluetooth, TF card playback, and AUX mode.

Skipping songs

- Press M button to skip to the next song.
- Press (M) button to skip to the previous song.next

Adjusting the volume

- · Press

 button to increase volume.
- Press = button to decrease the volume.

Answering/ending a call

- To answer a call, quick press the 3 button.
- To end a call, quick press the 🥎 button again.

Redial the last number

• Double quick press the 🦒 button, the last number called will be redialed.

Playing music from TF card

- Insert TF card into the TF card slot.
- Press 🐧 button to turn on the Bluetooth speaker.
- Press Mode button I to switch the Bluetooth speaker to TF card playback mode.

Charging the Bluetooth speaker

To charge the Bluetooth speaker, connect the supplied micro USB cable to the USB charging port and the other end to your computer or USB charging device. The LED indicator will flash when charging. When charging is completed, the LED indicator will stop flashing and stay solid areen.



Make sure you charge your Bluetooth speaker for at least 4 hours before using it for the first time.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.