



1. USB HOST
2. SD PLUG
3. Microphone A antenna
4. Microphone B antenna
5. MICROPHONE VOLUME  
Use this control to set the volume level of Microphone
6. ECHO FOR MICROPHONE
7. Treble
8. Bass
9. Master volume
- 10/11. 6.35mm Mic input
12. RCA Line Input/ RCA Line Output
13. Line in and MP3 Volume
14. Wireless Microphone A Volume
15. Wireless Microphone B Volume
16. Power switch of Wireless Microphone
17. DC 24 V connector
18. ON/OFF POWER SWITCH
19. AC POWER CONNECTOR
20. Handle Microphone A and Handle Microphone B

The AC inlet incorporates the voltage selector. Ensure that the main voltage source matches the voltage rating. Extract and place it according to the value. The selected one will be showed in the correct reading position.

▲220-240  
110-120▼ Device set at 110/120V AC  
115-230V AC 50-60Hz

## **FCC STATEMENT :**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

**Warning:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## **RF warning statement:**

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.