

## FCC NOTES

Note: This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation of the device.

CAUTION: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## TROUBLESHOOTING

PROBLEM	PROBABLE SOLUTIONS
Car does not move or runs slowly	<ul style="list-style-type: none"><li>• Make sure power switch on vehicle and transmitter are in the ON position</li><li>• Make sure the batteries in the vehicle and transmitter are installed properly</li><li>• Replace 9V battery in transmitter and AA batteries in the vehicle with fresh alkaline batteries</li></ul>
Car moves erratically or transmitter range is short	<ul style="list-style-type: none"><li>• There is radio interference in the area - change locations</li><li>• There is another R/C vehicle operating on the same frequency near by - move away from any other vehicle operating on the same frequency</li><li>• Make sure transmitter antenna is screwed in tight and fully extended</li><li>• Make sure transmitter battery connections are in good condition and replace battery</li></ul>
Car does not work after going through water or snow	<ul style="list-style-type: none"><li>• Allow car to dry thoroughly overnight</li><li>• Avoid driving in water or snow</li></ul>

**Questions or problems?**  
**BEFORE RETURNING TO STORE,**  
call our toll free help line at 1-800-728-7940  
for information and assistance  
Monday - Thursday 8:30AM - 5:30PM  
Friday 8:30AM - 3:00PM (EST)

Manufactured under license by:  
TEAM UP INTERNATIONAL, INC.  
4545 Enka Highway  
Morristown, TN 37813  
423-585-5300  
[www.teamup-usa.com](http://www.teamup-usa.com)

MADE AND PRINTED IN CHINA



## OWNER'S MANUAL

*Please read carefully before operating your vehicle. Keep these instructions for future reference as they contain important information*


**ATTENTION PARENTS:** It is recommended that this toy and all accessories be periodically examined for potential hazards and that any potentially hazardous parts be repaired or replaced.

### BATTERY REQUIREMENTS:

(4) AA batteries for vehicle and (1) 9V battery for transmitter (*not included*)


## SET-UP

1. Use a Phillips screwdriver to loosen the battery cover screw on the bottom of the car.
2. Insert (4) AA batteries into the battery compartment. Be sure to use the correct polarity as marked inside the battery compartment.
3. Replace the battery cover and tighten the screw securely (do not over tighten).
4. Move the power switch on the bottom of the car to the ON position.



## SET-UP (continued)

5. Remove the battery cover on the bottom of the transmitter.
6. Connect the 9V battery to the wire plug and insert battery into compartment.
7. Replace the battery cover.
8. Insert the transmitter antenna into the top of the transmitter and screw in tightly.
9. Move the power switch on the transmitter to the ON position




## RACE

1. Place car on smooth, flat surface and extend transmitter antenna fully.
2. To move car forward and backward in a straight line, move the left lever up and down.
3. To turn left or right while moving forward, move the right lever side to side while holding the left lever up.
4. To turn left or right while moving backward, move the right lever side to side while holding the left lever down.

NOTE: For maximum performance, hold the transmitter upright so the antenna points up (do not point the antenna at the car- this will reduce the signal range).

5. Adjust the steering alignment lever located on the bottom of the car if the car does not run straight when moving forward (refer to drawing on first page for location of steering alignment lever).



## BATTERY PRECAUTIONS

- Batteries should be inserted with the correct polarity.
- Do not short circuit battery contacts.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- Remove batteries if vehicle will not be used for a long period.
- Check the batteries regularly for leakage.
- Exhausted batteries should be removed from the toy.
- Do not dispose batteries in a fire - batteries may leak or explode.
- Use only the recommended batteries or batteries of equal quality/type.
- Do not recharge non-rechargeable batteries.
- Rechargeable batteries should always be charged under adult supervision.

### BATTERY PERFORMANCE NOTE:

For best performance use alkaline batteries (where disposable batteries are called for). If your vehicle is supplied with standard (carbon-zinc) batteries for initial use and/or demonstration purposes, we recommend replacing them with alkaline batteries when necessary. Battery life may vary depending on battery brand.

## SAFETY

- Do not operate during thunderstorms.
- Do not pick up your vehicle when it's moving.
- Avoid water, sand, and snow when operating your vehicle. In addition, do not submerge your vehicle or transmitter in water.
- Never operate your vehicle on the street or highway.
- Never operate your vehicle in a confined or crowded area, and do not use people or animals as obstacles.
- Do not run your vehicle into furniture, objects or hard surfaces, as this will cause damage to both the objects and the vehicle.
- Keep fingers, hair, and loose clothing away from the tires, gears, and motor while the vehicle is switched ON.
- Do not leave vehicle or transmitter near sources of heat or under direct sunlight for long periods of time.
- Do not leave vehicle or transmitter outside overnight- dampness is harmful to interior components.
- Remove all batteries when not in use to avoid accidental operation.
- Adult supervision is recommended when operating this vehicle.