

# User Manual

## (U2MCRM, U2MCRN)

Data Line

## **FCC NOTICE**

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES.  
OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITION:  
(1)THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND  
(2)THIS DEVICE MUST ACCEPT ANY INTERFERENCE  
RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE  
UNDERSIRED OPERATION.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures :

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit difference from that to which the receiver is connected.
- Consult the dealer of an experienced radio/TV technician for help.

NOTE : The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

## 1. Contents

**AIOS USB2.0 Multi memory cards reader**

**USB extension cable**

**Strap**

## 2. System requirement and Specification

PC	IBM compatible, I Mac, Power-book
OS	Win 98/SE/ME/2000/XP, Mac OS, Linux Win98 requires a device driver
Interface	USB2.0 high speed, USB 1.1 compatible
Size	74 x 35 x 1.6 mm
Weight	25g

### **3. Installation and Usage**

Windows ME/2000/XP doesn't require a device driver.

Windows 98/SE requires a device driver which can be downloaded at [www.dlbtech.com](http://www.dlbtech.com)

When the device is connected in USB port, two or three removable disks will be created in the windows explorer. (the model without an internal memory will be showing two and the model with an internal memory will be showing three). Then device supported memory cards can be inserted and reading/writing jobs can be executed. LED will be blinking as reading/writing jobs occurred.

### **4. Caution**

Do not remove the device from USB port or do not remove memory cards when LED is still blinking. It may cause damage on the memory cards or data in them.

#### **Data Line**

Address: Doosan 114-1601,Dogokri,Wabueup,Namyangjusi,  
Kyungkido,korea  
Tel:82-31-521-9393  
Fax:82-31-521-9390  
[www.dlbtech.com](http://www.dlbtech.com)