

USER INSTRUCTION OF R/C LAND HUNTER

1. Product Name: Remote Controlled Land Hunter


Material: Plastic and electronic components

2. Installation of Batteries;

A. Controller (1 x 9v Battery)



B. Truck (6x "AA" 1.5V Batteries)




3. Basic operation

A. Front wheels alignment



B.



4. Control Range: 20 meters (outdoor) By 27MHz/40MHz/49MHz

Caution

- If the power of the batteries become insufficient, the running speed of the car will be reduced obviously.
- Improper use of battery may lead to heat, break, or electrolyte leak, please use according to the following requirement:
 - Always make correct +/– connections.
 - Immediately stop use whenever the battery is wetted
 - Never make the battery short circuit, disassemble or throw it into fire.
- Store the car away from fire source or high temperature
- The car contains complex electronic circuits and many electronic components, do not try to disassemble or restructure it.
- Please keep the packing material to avoid pollution to the environment
- Always cut off power after use. Otherwise the battery will lose power gradually, with use life gradually shortened.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.