

WARNING: RF Hazard Information

THE ANTENNA(S) USED FOR THIS TRANSMITTER MUST BE FIXED-MOUNTED ON OUTDOOR PERMANENT STRUCTURES. RF EXPOSURE COMPLIANCE IS ADDRESSED AT THE TIME OF LICENSING, AS REQUIRED BY THE RESPONSIBLE FCC BUREAU(S) INCLUDING ANTENNA CO-LOCATION REQUIREMENTS OF PARA. 1.1307(B)(3).

WARNING!

THE VOLTAGES AND CURRENTS IN THIS EQUIPMENT ARE DANGEROUS. PERSONEL MUST, AT ALL TIMES, OBSERVE SAFETY WARNINGS, INSTRUCTIONS, AND ANY REGULATIONS.

This owner's manual is intended as a general guide for trained and qualified personnel who are aware of the dangers that are inherent in the handling and operation of potentially hazardous electrical and electronic circuits. It is not the intent of this manual to provide a complete set of safety instructions or precautions that should already be understood by trained or experienced personnel in using this or other types of electronic equipment.

The installation, operation, and maintenance of this equipment involves risks to personnel and also to the equipment. Nexus Broadcast Products shall not be responsible for injury or damage that is the result of improper procedures or use by persons improperly trained or lacking the knowledge to perform associated tasks.

All local codes for building, safety, fire, or related standards must be observed. Consult local authorities for the standards for the area or region where the equipment will be installed and put in use.

WARNING!

AT ALL TIMES DISCONNECT AC/MAINS POWER BEFORE OPENING COVERS, DOORS, ENCLOSURES, PANELS, OR PROTECTIVE SHIELDS THAT EXPOSE LIVE CIRCUITS. USE ANY GROUNDING STICKS OR OTHER SHORTING PROBES TO DRAIN ENERGY FROM CIRCUITS BEFORE SERVICING. NEVER PERFORM MAINTENANCE, MAKE ADJUSTMENTS, OR SERVICE THE EQUIPMENT WHEN ALONE OR FATIGUED.

WARNING!

IF ELECTROLYTIC OR OIL FILLED CAPACITORS ARE UTILIZED IN THE EQUIPMENT AND THE COMPONENT APPEARS LEAKY, OR IS BULGING, OR IF THE CASE OR COVERING OF THE COMPONENT APPEARS DAMAGED OR DISTRESSED ALLOW SUFFICIENT TIME FOR THE UNIT TO COOL OR FULLY DISCHARGE BEFORE SERVICING. SERVICING HOT OR LEAKY CAPACITORS CAN CAUSE A RUPTURE OF THE CASE AND POSSIBLE INJURY.

Should accident or injury occur personnel engaged in the installation, operation, or service of the equipment should seek proper medical attention. It is advisable that such personnel have familiarity with first-aid practices.