

Vantos User's manual

1. Getting Started

System Requirements:

An available personal computer has USB2.0 or 1.1 port.

users require Windows® 98SE/Me/2000/XP.

Standard 3.5" IDE hard disk drive (Option)

All current computer systems that have existing USB 1.1 ports can be used with the Vantos external hard drive. A USB 2.0 PCI adapter card and the included USB 2.0 certified cable are required for Hi-Speed USB 2.0 performance.

2. Connecting USB 2.0 Drive

1. Power on your computer.
2. Plug the end of the AC power connector with the flat side facing up into the power supply socket located on the back of the drive.
3. With the AC power connector connected, connect the power cord into an available electrical outlet. Push the power switch and verify that the power LED is lit.
4. Connect one end of the USB cable into an available USB port on your computer.
5. Plug the other end of the USB cable into the corresponding interface port on the back of the external hard drive.

3. Installing the Drivers

Windows Me/2000/XP

1. After connecting the drive Windows will immediately detect your Vantos USB 2.0 external hard drive and install the drivers. This may take several minutes.
2. If prompted, restart your computer. Otherwise, skip to the next step.
3. A new hard drive icon will appear in your My Computer window. Your Vantos USB 2.0 external hard drive is preformatted as one FAT32 partition and is now ready to use.

* To reformat or partition the drive in Windows 2000 and XP

1. Right-click on the My Computer icon located on your desktop and select Manage from the shortcut menu to open the Computer Management window.
2. Click on Disk Management on the left side of the window.
3. In the bottom half of the window, right-click on the Unallocated portion of the drive and select New Partition from the shortcut menu.

4. Click Next to proceed with the New Partition Wizard. You may select the partition file type, specify the partition size, and assign a drive letter or path.
5. Click Finish to confirm your settings.

**** Disconnecting USB 2.0 external hard disk drive**

Double-click on the Windows Unplug or Eject Hardware icon in your system tray (located in the bottom right corner of your screen—see the dialog box below for a depiction of this icon).

Select and highlight USB 2.0 hard disk Device from the list, then click Stop. To confirm your selection of the drive to be disconnected, click OK. You may now safely disconnect your drive.

On-line service

www.vantos.co.kr

Manufacturer : Seong il data systems Co., Ltd.

746-5, Seoil Bldg. 4F, Banpo-Dong Seocho-Ku
Seoul, Korea

Tel : +822-516-0162

Fax: +822-544-1516

FCC Information

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This Device may not cause harmful interface, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for CLASS B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try correct the interference by one or more of the following measures:

- 1.1. Reorient or relocate the receiving antenna.
- 1.2. Increase the separation between the equipment and receiver.
- 1.3. Connect the equipment into an outlet on a circuit different from that to which receiver is connected.
- 1.4. Consult the dealer or experienced radio/TV technician for help.

WARNING

Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.