

iLuvTM

THANK YOU FOR YOUR PURCHASE

iLuvTM

Model : i720

Instruction Manual

©2008 www.i-Luv.com

iLuv is a trademark of JWIN Electronics Corp.

iPod is a trademark of Apple Inc., registered in the U.S. and other countries.

The illustrated product and specifications may differ slightly from that supplied.

Designed in New York, USA / Made in China

Remote Control and FM Transmitter with Bluetooth Caller ID

INTRODUCTION


Thank you for purchasing the i720. Unpack the unit and make sure all the accessories are put aside so they will not be lost. This product provides full control of your iPod and hands-free operation of your Bluetooth mobile phone*.

* Compatible with any iPod model with 30Pin connector.

* Your Bluetooth mobile phone must support HSP and HFP profiles to use hands-free and voice dialing.



Location of Controls



- 1. HOLD Switch
- 2. PREV / RW Button
- 3. NEXT / FF Button
- 4. VOLUME - Button
- 5. VOLUME + Button
- 6. MULTI-FUNCTION Button
- 7. LCD Screen
- 8. PLAY / PAUSE Button
- 9. ON / OFF / FM TRANSMITTER Switch

TABLE OF CONTENTS

Introduction

Location of Control 1

Getting Started

Authentication of your iPod 3

Connecting the Earphones and your iPod 3

Operational Instructions

Bluetooth Functions 4

Pairing Mode 4

Call Accept / End / Transfer / Reject 4

Voice Dialing 4

Ending Bluetooth Connection 5

FM Transmitter Functions 5

FM Transmitter Mode 5

iPod Functions 5

Controlling your iPod 5

Backlight Timeout 5

Troubleshooting Guide

No sound 6

Poor radio reception 6

Features and Specifications

Features 7

Bluetooth hands-free 7

iPod remote control 7

FM Transmitter 7

Other features 7

Specifications 8

User Safety Guide

Important Safety Warnings 9

Important Safety Instructions 9

Additional Safety Instructions 10

About Electromagnetic Interference (EMI) 11

FCC Notice to U.S. Users 11

Industry Canada Notice to Canadian Users 12

Additional Information

Helpful Tips on Getting Clear Sound 13

GETTING STARTED

Authentication of your iPod

In order to support a variety of iPod models, the i720 has an authentication procedure that takes a few moments to complete. During this procedure, bars will appear on the LCD screen in increasing number (see image below) until complete. Authentication is finished when the bars disappear.



Connecting the Earphones and your iPod

1. Plug the 3.5mm plug into the headphone jack as shown here.
2. With the 30pin connector attached to your iPod, attach the mini USB plug to the mini USB jack on the i720 as shown.



OPERATIONAL INSTRUCTIONS

Bluetooth Functions

Pairing Mode

1. Press and hold **MULTI-FUNCTION** button for approximately five (5) seconds.
2. The Bluetooth symbol on i720 LCD will flash repeatedly and a confirmation "double beep" will sound.
3. If your mobile phone is equipped with Bluetooth wireless technology, follow the directions on your mobile phone to set it to **SEARCH** mode.
4. Your phone will find the i720 and will identify it on the LCD screen. To confirm, press **YES** or **OK**.
5. When asked for a **PIN** code or number, enter "0000," (four zeros) and press **YES** or **OK** to confirm.
6. Your mobile phone is now successfully paired with i720. Bluetooth symbol light remain on steadily.

Call Accept / End / Transfer / Reject

1. Press the **MULTI-FUNCTION** button once when call is incoming to answer the call. Press again to end the call. The unit has a built in microphone so the caller can hear you.
2. To transfer a call, press and **MULTI-FUNCTION** button for three (3) seconds during call activating.
3. To reject a call, press **PREV / RW** button when call is incoming.

Voice Dialing

Press the **MULTI-FUNCTION** button when there is no incoming call or call in progress in order to dial.

Note: You can only dial a call using voice dialing if your Bluetooth mobile phone supports voice dialing.

OPERATIONAL INSTRUCTIONS

Ending Bluetooth Connection

1. While Bluetooth connection is active, press and hold **MULTI-FUNCTION** button for approximately five (5) seconds to re-enter pairing mode and the Bluetooth symbol will begin to blink again.
2. While the Bluetooth light is blinking, press the **MULTI-FUNCTION** button once to turn off Bluetooth mode. Bluetooth light will turn off.

FM Transmitter Functions

FM Transmitter Mode

1. Slide the **ON / OFF / FM TRANSMITTER** Switch to the ON position.
2. To search the dial for available frequencies, press the **VOLUME -** or **VOLUME +** buttons.

Note:

- When using the FM transmitter while paired with a Bluetooth phone, calls will be heard through the radio speakers.

iPod Functions

Controlling your iPod

This unit provides control of your iPod through the use of compatible controls on the unit itself.

- For the previous track press the **PREV / RW** button.
- To rewind, press and hold the **PREV / RW** button.
- To skip to the next track, by press the **NEXT / FF** button.
- To perform a fast scan, press and hold the **NEXT / FF** button.
- To adjust the sound level, press the **VOLUME -** or **VOLUME +** buttons.
- To play or pause music, press the **PLAY/PAUSE** button.

Backlight Timeout

- When first powered ON, the backlight on the LCD display will light up and remain on for 25 seconds.
- After the backlight has gone out but the power remains ON, the backlight will light again for 15 seconds.
- To turn on the backlight only, press any button except the **MULTI-FUNCTION** or **PLAY** buttons.
- Press all other buttons a second time to activate their functions.

TROUBLESHOOTING GUIDE

No sound

- Your iPod is not connected into the 30pin connector properly. Connect again.
- Your car radio is not turned on. Turn on the radio.
- The i720 is not paired with your mobile phone. Follow pairing instructions in this manual
- Your iPod is not turned on. Turn on your iPod.
- Your mobile phone is not turned on. Turn on your phone
- The i720 is not turned on. Turn on i720.

Poor radio reception

- The i720 is tuned to a frequency that is used by a local radio station. Find a frequency with no interference.
- The antenna on your car is not extended. Extend your car antenna.

FEATURES AND SPECIFICATIONS

Features

Bluetooth hands-free

- Answer or make calls wirelessly
- Call reject, call transfer and voice dial
- Communication range up to 33ft (10m)
- Compliant with Bluetooth V2.0
- Supports HSP and HFP profiles
- Caller ID display on LCD screen

iPod remote control

- Play / Pause
- Fast forward / Fast rewind
- Skip to Next / Previous song
- Volume Up / Down

FM Transmitter

- Transmit songs on your iPod to any FM radio
- Wide range of selectable frequencies
- Program favorite FM frequencies
- Displays FM frequencies on the LCD

Other features

- Authentic aluminum earphones with stereo sound
- Liquid crystal display (LCD) with backlight and caller ID
- Compatible with iPod models
- No battery or software installation required
- Built-in clothing clip
- Hold On / Off

FEATURES AND SPECIFICATIONS

Specifications

Bluetooth

- Version: V2.0 compliant
- Supported profiles: HSP and HFP
- Communication range: up to 33ft (10m)

FM transmitter

- Frequency range: 88.1MHz – 107.9 MHz

* Features and specifications are subject to change without prior notification.
The unit dimensions and weights are approximate

USER SAFETY GUIDE

IMPORTANT SAFETY PRECAUTIONS



Instructions on Environmental Protection

Do not dispose of this product in the usual household garbage at the end of its life cycle; bring it to a collection point for the recycling of electrical and electronic appliances. This symbol on the product means the instructions for use or the packing will inform about the methods for disposal. The materials are recyclable as mentioned in its marking. By recycling, material recycling, or other forms of re-utilization of old appliances, you make an important contribution to protect the environment. Please inquire at your local community administration for the authorized disposal location.

Important Safety Warnings

1. FCC regulations state that any change or modification to the equipment, not expressly approved by maker or its authorized parties, could void user's authority to operate this equipment.
2. To prevent fire or electric shock, do not expose the unit to rain or moisture.
3. Never attempt to open the cabinet. Always refer servicing to a qualified technician.

Important Safety Instructions

1. **READ INSTRUCTIONS** - All safety and operating instructions should be read before the appliance is operated.
2. **RETAIN INSTRUCTIONS** - The safety and operating instructions should be retained in a secure place for future reference.
3. **HEED WARNINGS** - All warnings on the appliance and in the operating instructions should be observed.
4. **FOLLOW INSTRUCTIONS** - All operating and use instructions should be followed.
5. **WATER AND MOISTURE** - The appliance should not be used near water. For example: near a bathtub, kitchen sink, laundry tub, and/or swimming pool.
6. **HEAT** - The appliance should be situated away from heat sources such as radiators, heat registers, stoves, or other appliances (including amplifiers) that produce heat.
7. **POWER SOURCES** - The appliance should be connected to a power supply only of the type described in the operating instructions or as marked on the appliance.
8. **CLEANING** - The appliance should only be cleaned with a dry cloth.
9. **OBJECT AND LIQUID ENTRY** - Care should be taken so that objects do not fall and liquids are not spilled into the device's openings.

USER SAFETY GUIDE

IMPORTANT SAFETY PRECAUTIONS – CONTINUED

10. **CARTS AND STANDS** - The appliance should be used only with a cart or stand that is recommended by the manufacturer. An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn causing possible injury to the user and/or damage to the unit.



11. **DAMAGE REQUIRING SERVICE** - The appliance should be serviced by qualified service professional when:
 - a. Objects have fallen into, or liquid has been spilled into the appliance's apertures.
 - b. The appliance has been exposed to rain.
 - c. The appliance has been dropped and suffered damage.
 - d. The appliance does not appear to operate normally, or exhibits a change in performance.

12. **SERVICING** - The user should not attempt to service the appliance beyond what is described in the user's operating instructions. All other servicing should be referred to qualified service professional.

13. **LEAD AND MERCURY** - This product may contain lead and/or mercury. Disposal of these materials may be regulated by your local authorities due to environmental considerations. For more detailed disposal or recycling information, please contact your local authorities or the EIA (Electronic Industries Alliance) - <http://www.eiae.org>

Additional Safety Instructions

- When not in use, keep your device in a safe place where it will not be bent or crushed.
- Do not listen to music with high volume while driving. Warning horn sounds may not be heard which could result in a traffic accident.

NOTE: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Refer to 47 CFR Sec. 15.21.

USER SAFETY GUIDE

About Electromagnetic Interference (EMI)

This device is designed and manufactured not to exceed the exposure limit for radio frequency energy, which is set by the Federal Communications Commission of the U.S government.

The term "EMI" is short for the electromagnetic interference caused by the electromagnetic field generated by electronic devices. In fact, most electrical appliances and devices emit electric and magnetic fields, and most of modern electronic devices are susceptible to electromagnetic interference (EMI) if they are inadequately shielded or designed.

- If you use any personal medical device, such as a pacemaker, please consult the manufacturer of the device to determine if it is adequately shielded from electromagnetic interference. Your physician may assist you in obtaining this information.
- Please turn off this device if you are instructed to do so, especially on an airplane and in a hospital.
- Please keep away from the medical instruments in a hospital or medical unit while using this device.

FCC Notice to U.S. Users

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Refer to 47 CFR Sec. 15.19.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications, which can be determined by turning the equipment off and on, the user is encouraged to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

USER SAFETY GUIDE

Industry Canada Notice to Canadian Users

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation of the device. Refer to IC RSS 210 Sec. 5.11. The term "IC" before the certification or registration number only means that the registration was performed based on a Declaration of Conformity and that Industry Canada technical specifications were met. It does not imply that Industry Canada (IC) approved this equipment. Refer to Self-Marking 6(f) and RSP 100 Sec. 4.

ADDITIONAL INFORMATION

Helpful Tips on Getting Clear Sound

- An FM transmitter employs frequency modulation to transmit songs to an FM radio, which can be disturbed by a strong FM signal nearby. Thus, before transmitting songs with this unit, it is very important to select a clear FM station, one which has no other broadcasting and renders only static noise.
- The sound quality of a FM transmitter also depends on the direction of its built-in antenna and its surroundings. If you hear some static noises while listening to music using the FM transmitter, rotate or move the FM transmitter around until you get a clearer sound.
- If a battery is low, the sound quality may also be poor. In this case, charge your iPod first and try it again.



Visit our website at www.i-Luv.com

iLuv is a trademark of jWIN Electronics Corp. iPod and iPhone are a trademarks of Apple Inc. All logos and brands are property of their respective owners. iPod or iPhone is not included in this package. The Bluetooth word mark and logos are owned by Bluetooth SIG, Inc. and any use of such marks by jWIN Electronics Corp. is under license. Mobile phone not included in this package. Features and specifications are subject to change without prior notification.

©2008 jWIN Electronics Corp., All rights reserved. No portion of this printed material or product enclosed herewith including design, shape, and graphics may be reproduced or transmitted in any form without the expressed written consent of jWIN Electronics Corp., by any means electronic or mechanical including photocopying, recording, or use of an information storage retrieval system. Any unauthorized distribution or reproduction of this printed material, or any portion thereof, will be prosecuted to the fullest possible extent of the law.

Printed in China

iLuv | 14

i720 | V10M10_IM_EN_03282008