




RAZER WIRELESS MOUSE

RZ01-0390

IMPORTANT PRODUCT INFORMATION GUIDE

WHAT'S INSIDE

- Razer Wireless Mouse




- A. Left mouse button
- B. Right mouse button
- C. Razer™ HyperScroll tilt wheel (press) / AI Prompt Master button* (press and hold)
- D. Scroll mode button
 - Free-Spinning mode
 - Tactile Cycling mode
- E. Mouse button 5
- F. Mouse button 4
- G. Razer™ Chroma RGB underglow
- H. USB Type C port
- I. PTFE mouse feet
- J. Mode switch
 - Wireless (green)
 - Wired/Off (red)
- K. Razer™ Focus Pro 30K Optical Sensor
- L. Multifunction button
 - Switch connection (HyperSpeed/Bluetooth)
 - Bluetooth pairing
- M. USB dongle compartment


! The DPI stages are as follows: 400, 800, 1600 (default), 3200 and 6400. The DPI stages and polling rate can be customized using Razer Synapse.

*Razer Synapse required

- 2.4GHz HyperSpeed Wireless dongle



- USB Type A to USB Type C cable



- Important Product Information Guide

WHAT'S NEEDED


PRODUCT REQUIREMENTS

- USB Type A port or Bluetooth Connectivity

RAZER SYNAPSE REQUIREMENTS

- Windows® 10 64-bit
- Internet connection for software installation

LET'S GET YOU COVERED




*Your product's serial
number can be found here.*




Register your product and score exclusive benefits
razerid.razer.com/warranty

GETTING STARTED

CHARGE YOUR MOUSE




i For best results, connect your mouse directly to your computer's USB port using the provided cable.





Battery Status	Underglow Status Indicator
Full	Static Green
High	Breathing Green
Mid	Breathing Yellow
Low	Breathing Red
Critical	Blinking Red

CONNECT TO YOUR DEVICE

USING WIRED MODE



2




USB
Type A

WIRELESS MODES ON 2.4GHz or BLUETOOTH (⌚)


Use the multifunction button to toggle across multiple devices/slots.

Assigned Slot	Underglow Indicator Color
Hyperspeed	White
⌚ 1	Blue
⌚ 2	Green
⌚ 3	Yellow

USING 2.4GHz WIRELESS MODE





2



USB Type A


3






i Install Razer Synapse when prompted or download the installer from razer.com/synapse

USING BLUETOOTH MODE





Cycle between
Bluetooth (⌚) slots



Press repeatedly


Assigned Slot | **Underglow Indicator Color**

HyperSpeed	White
------------	-------

⌚ 1	Blue
-----	------

⌚ 2	Green
-----	-------


⌚ 3	Yellow
-----	--------




Pairing
Slow Blinking

4


Pair to your device



5



Re-Pairing Your Mouse




Cycle between
Bluetooth (BT) slots



Press repeatedly

Assigned Slot	Underglow Indicator Color
HyperSpeed	White
BT 1	Blue
BT 2	Green
BT 3	Yellow




Activate Pairing



Press and hold
for 3 seconds


USING YOUR RAZER WIRELESS MOUSE

SWITCHING SCROLL MODES



i You can also use Razer Synapse to set the mouse to Smart-Reel mode where the Razer™ HyperScroll Tilt Wheel will automatically switch between Free-Spinning mode and Tactile Cycling mode.

INVOKING THE AI PROMPT MASTER*



*requires Razer

i Install Razer Synapse when prompted or download the installer at razer.com/synapse. Use the Razer Synapse app to customize your mouse's DPI, lighting, button configurations, and create various profiles suited for different tasks.

Find out more about your professional-grade mouse at support.razer.com

SAFETY AND MAINTENANCE

SAFETY GUIDELINES

In order to achieve maximum safety while using your Razer Wireless Mouse, we suggest that you adopt the following guidelines:

Should you have trouble operating the device properly and troubleshooting does not work, unplug the device and contact the Razer hotline or go to support.razer.com for assistance.

Do not take apart the device (doing so will void your warranty) and do not attempt to operate it under abnormal current loads.

Keep the device away from liquid, humidity or moisture. Operate the device only within the specific temperature range of 0°C (32°F) to 40°C (104°F). Should the temperature exceed this range, unplug and/or switch off the device in order to let the temperature stabilize to an optimal level.

Avoid looking directly at the tracking beam of your mouse or pointing the beam in anyone else's eye. Note that the tracking beam is NOT visible to the naked human eye and is set on an Always-On mode.

COMFORT

Research has shown that long periods of repetitive motion, improper positioning of your computer peripherals, incorrect body position, and poor habits may be associated with physical discomfort and injury to nerves, tendons, and muscles. Below are some guidelines to avoid injury and ensure optimum comfort while using your Razer Wireless Mouse.

- Position your keyboard and monitor directly in front of you with your mouse next to it. Place your elbows next to your side, not too far away and your keyboard within easy reach.
- Adjust the height of your chair and table so that the keyboard and mouse are at or below elbow-height.
- Keep your feet well supported, posture straight and your shoulders relaxed.
- During gameplay, relax your wrist and keep it straight. If you do the same tasks with your hands repeatedly, try not to bend, extend or twist your hands for long periods.
- Do not rest your wrists on hard surfaces for long periods. Use a wrist rest to support your wrist while doing tasks.
- Customize the keys on your keyboard to suit your style in order to minimize repetitive or awkward motions while doing tasks.

- Do not sit in the same position all day. Get up, step away from your desk and do exercises to stretch your arms, shoulders, neck and legs.

If you should experience any physical discomfort while using your mouse, such as pain, numbness, or tingling in your hands, wrists, elbows, shoulders, neck or back, please consult a qualified medical doctor immediately.

MAINTENANCE AND USE

The Razer Wireless Mouse requires minimum maintenance to keep it in optimum condition. Once a month we recommend you unplug the device from the computer and clean it using a soft cloth or cotton swab to prevent dirt buildup. Do not use soap or harsh cleaning agents.

To get the ultimate experience in movement and control, we highly recommend a premium mouse mat from Razer. Some surfaces will cause undue wear on the feet requiring constant care and eventual replacement.

Do note that the sensor of the Razer Wireless Mouse is ‘tuned’ or optimized especially for the Razer mouse mats. This means that the sensor has been tested extensively to confirm that the Razer Wireless Mouse reads and tracks best on Razer mouse mats.

LEGALESE

COPYRIGHT AND INTELLECTUAL PROPERTY INFORMATION

©2025 Razer Inc. All rights reserved. Razer, the triple-headed snake logo, Razer logo, “For Gamers. By Gamers.”, and “Razer Chroma” logo are trademarks or registered trademarks of Razer Inc. and/or affiliated companies in the United States or other countries. Actual product may differ from pictures. All other trademarks are the property of their respective owners. Warranty not valid outside of product’s intended region.

Windows and the Windows logo are trademarks or registered trademarks of the Microsoft group of companies.

Apple and macOS are trademarks of Apple Inc., registered in the U.S. and other countries and regions.

Razer Inc. (“Razer”) may have copyright, trademarks, trade secrets, patents, patent applications, or other intellectual property rights (whether registered or unregistered) concerning the product in this guide. Furnishing of this guide does not give you a license to any such copyright, trademark, patent, or other intellectual property right. The Razer Wireless Mouse (the “Product”) may differ from pictures, whether on the packaging or otherwise. Razer assumes no responsibility for such differences or for any errors that may appear. Information contained herein is subject to change without notice.

LIMITED PRODUCT WARRANTY

For the latest and current terms of the Limited Product Warranty, please visit razer.com/warranty.

LIMITATION OF LIABILITY

Razer shall in no event be liable for any lost profits, loss of information or data, special, incidental, indirect, punitive or consequential or incidental damages arising in any way out of distribution of, sale of, resale of, use of, or inability to use the product. In no event shall Razer’s liability exceed the retail purchase price of the product.

GENERAL

These terms shall be governed by and construed under the laws of the jurisdiction in which the product was purchased. If any term herein is held to be invalid or unenforceable, then such term (in so far as it is invalid or unenforceable) shall be given no effect and deemed to be excluded without invalidating any of the remaining terms. Razer reserves the right to amend any term at any time without notice.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC RF Rules. This equipment must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and consider removing the no-collocation statement.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

KDB784748 D01 v08 (P4)

Caution!

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Canada Statement

RSS-Gen(P23):

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

1) L'appareil ne doit pas produire de brouillage;

2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

RSS-102(P9):

The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

Le dispositif rencontre l'exemption des limites courantes d'évaluation dans la section 2.5 de RSS 102 et la conformité à l'exposition de RSS-102 rf, utilisateurs peut obtenir l'information canadienne sur l'exposition et la conformité de rf.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

Cet émetteur ne doit pas être Co-placé ou ne fonctionnant en même temps qu'aucune autre antenne ou émetteur. Cet équipement devrait être installé et actionné avec une distance minimum de 20 centimètres entre le radiateur et votre corps.

Declaration of Conformity

Hereby, Razer Inc. declares that the radio equipment type gaming mouse RZ01-0390 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

razer.com/legal/compliance

2.4G equipment

- Operating frequency range: 2402-2480MHz
- Maximum out power(E.I.R.P): 9.15dBm (8.22mW), 2.4G SRD
- Maximum out power(E.I.R.P): 9.15dBm (8.22mW), 1Mbps, BLE
9.14dBm (8.20mW), 2Mbps, BLE